



## PackMojo 56863 Foam Insert Customization Kit Instructions

[Home](#) » [PackMojo](#) » PackMojo 56863 Foam Insert Customization Kit Instructions 



**PACKMOJO**

Customizing the  
Foam Insert

### Contents

- [1 56863 Foam Insert Customization Kit](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)

### 56863 Foam Insert Customization Kit

1. Place item(s) on top of foam in the desired packing position.  
Leave enough space for complete foam blocks between each item and between items and the sides of the case.
2. Trace the outline of each item on the foam using a marker or soft pencil.
3. Remove the marked blocks to customize the foam insert.  
Leave more blocks in place around the edges for a tighter fit.



**PACKMOJO**

### Documents / Resources

<div>Customizing the Foam Insert</div> <div><div>1. Place item(s) on top of foam in the desired packing position. Leave enough space for complete foam blocks between each item and between items and the sides of the case.</div><div>2. Trace the outline of each item on the foam using a marker or soft pencil.</div><div>3. Remove the marked blocks to customize the foam insert. Leave more blocks in place around the edges for a tighter fit.</div></div>	<div>PackMojo 56863 Foam Insert Customization Kit [pdf] Instructions</div> <div>56863, 792363, 568630, 56863 Foam Insert Customization Kit, 56863, Foam Insert Customization Kit, Insert Customization Kit, Customization Kit</div>
--	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.