



peak design M-WM-AA-CH-WEB-1 Wall Mount Instructions

[Home](#) » [peak design](#) » peak design M-WM-AA-CH-WEB-1 Wall Mount Instructions 

peak design M-WM-AA-CH-WEB-1 Wall Mount



Contents

1

MOUNT INSTALLATION

2

Documents / Resources

2.1

References

3

Related Posts

MOUNT INSTALLATION

1. Select a mounting location. Wall Mount attaches with an adhesive back. See recommended mounting surfaces

below.

Smooth Surfaces

(e.g. tile, metal, glass)

Mount with no issues, prep with provided wipe.

Porous Surfaces

(e.g. drywall, painted walls, wood)

Mount with caution. Removal may damage surface. Do not prep with provided wipe.

- 2. If mounting on smooth surface, clean surface with the provided wipe. Allow 5 minutes to dry.
- 3. Remove adhesive backing and attach to desired location. Press down firmly for 30 seconds. For proper bond, wait 24 hours before use.




Wait 24 hours before use.

Failure to wait a full 24 hours will result in a weak bond.



Documents / Resources

	<p>peak design M-WM-AA-CH-WEB-1 Wall Mount [pdf] Instructions M-WM-AA-CH-WEB-1 Wall Mount, M-WM-AA-CH-WEB-1, Wall Mount, Mount</p>
---	--

References

- [Peak Design | Wall Mount | Peak Design Official Site](#)