

PowerFlex Holster Doc Hub User Guide



Contents [[hide](#)]

[1 Installing Holsters](#)

[2 Documents / Resources](#)

[2.1 References](#)

Installing Holsters

Materials needed:

- Holster (provided by PowerFlex)
- Power drill
- Drill bits (Phillips, hex, torx, flathead)
- Assorted screws for various surface types (most common are metal, brick, concrete, and drywall)

Powerflex supplies 3 holster types – standard, J-hook, and Z. Examples of each are shown below.




PowerFlex Support Line: [833-479-7359](tel:833-479-7359)



If the existing holster is broken but the holes are intact, simply remove the broken holster and replace with a new one.


If new holes need to be drilled, drill 4 holes then mount the holster with the appropriate screws.

Documents / Resources

	<p>PowerFlex Holster Doc Hub [pdf] User Guide</p> <p>Holster Doc Hub, Holster, Doc Hub, Hub</p>
---	---

References

- [User Manual](#)



Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.