



**17963, 17660
Black Split Top
QB2**



QuickBOLT 17963, 17660 Black Split Top QB2 Installation Guide

[Home](#) » [QuickBOLT](#) » QuickBOLT 17963, 17660 Black Split Top QB2 Installation Guide 

Contents

- [1 QuickBOLT 17963, 17660 Black Split Top QB2](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 RECOMMENDED MATERIALS](#)
- [6 INSTALLATION INSTRUCTIONS](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



QuickBOLT 17963, 17660 Black Split Top QB2



Specifications

- Product Name: AHJ CONDENSED PERMIT PACKAGE 2024
- Version: 5
- Compatible with: Asphalt, EPDM, & TPO Roofs
- Patent Number: #8448407
- Manufacturer: A Division of QuickScrews International Corp

Product Usage Instructions

Recommended Materials:

Ensure you have the following materials before installation:

- MFG approved sealant
- L-Foot
- Bolt

Installation Instructions:

1. Locate and mark the rafter where the installation will take place.
2. Pre-drill the hole at the marked location.

3. (Optional) Fill the predrilled hole with MFG approved sealant.
4. (Optional) Place a ring of sealant around the bottom of the L-Foot.
5. Insert the Bolt into the L-Foot.

FAQ

- **Q: Do I need to use sealant during installation?**

- A: While it is optional, using MFG approved sealant is recommended to ensure proper sealing and waterproofing.

- **Q: Can this product be used on other types of roofs apart from asphalt, EPDM, and TPO?**

- A: This product is specifically designed for use on asphalt, EPDM, and TPO roofs. It is not recommended for other roof types.

RECOMMENDED MATERIALS

- Tools to locate and mark rafter
- Drill with a 15/64" drill bit
- MFG approved sealant (optional)
- 1/2" Nut Setter

INSTALLATION INSTRUCTIONS

1. Locate and mark the rafter
2. Predrill the hole
3. Optional: Fill the predrilled hole with MFG approved sealant




4. Optional: Place a ring of sealant around the bottom of the Microflashing® washer
5. Place the Microflashing®
6. Insert the Bolt into the L-Foot
7. Drive the Bolt until the Microflashing® is compressed



To compress Microflashing® properly with QB2 use a 150 minimum torque lbs/inch The Bolt will compress the

Microflashing® and when fully compressed the L-Foot will not rotate.

Documents / Resources

	<p>QuickBOLT 17963, 17660 Black Split Top QB2 [pdf] Installation Guide 17963, 17660, 17963 17660 Black Split Top QB2, 17963 17660, Black Split Top QB2, Split Top QB2, Top QB2, QB2</p>
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.