



SILVERSTONE XAC-MK-4710 Socket Mounting Kit User Manual

[Home](#) » [SilverStone](#) » SILVERSTONE XAC-MK-4710 Socket Mounting Kit User Manual 

SILVERSTONE XAC-MK-4710 Socket Mounting Kit




Contents


- [1 Other Models](#)
- [2 Installation Instruction](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Other Models


XAC-MK-4710



XAC-MK-4189



Installation Instruction



1. Please wear ESD gloves to protect the processor and CPU socket before installation process
2. Install the processor first with the plastic carrier. Align the golden color triangle mark with the hollow triangle

mark on the carrier, then align the key on the processor IHS cover and side, push the processor and confirm the 4 clips securely locked (**Figure 1 &2**)

Note: the carrier latches must be fully engaged with the keying slots on the edges of the processor and the processor must be securely seated on the carrier after insertion.

Figure 1





Figure 2



1. Hollow Triangle Marker on the Carrier
2. Pin-1 Golden Triangle Marker both on CPU Top and Bottom Substrate
3. Solid Triangle Marker on the Carrier
3. Remove the heatsink from its packaging and remove the protection cover of Thermal Interface Material (TIM). The required amount of TIM has been pre-applied on the bottom of the heatsink. Inspect the pre-applied TIM for any damage before use.
4. Identify processor Pin 1 and onboard socket Pin 1 to decide the heatsink installation direction; for certain motherboards, the Pin 1 location will be different with CPU1 and CPU2. (**Figure 3 & 4**)

Note: The complete assembly of processor, carrier, and heat sink is called Processor Heat Sink Loading Module (PHLM) or Processor Heat Sink Module (PHM).

Figure 3





Figure 4



5. Before assembling PHM on bolster plate, follow the sticker instructions to ensure all wires are in unlocked position. Install PHM on bolster plate, and move all wires to locked position, then use Torx T30 screwdriver to tighten each nut of 8 LBF-IN (0.904 N-M) (**Figure 5 & 6**)

Figure 5





Figure 6




Customer Support

www.silverstonetek.com



Documents / Resources



[SILVERSTONE XAC-MK-4710 Socket Mounting Kit](#) [pdf] User Manual
MK-4189, MK-4710, XAC-MK-4710 Socket Mounting Kit, XAC-MK-4710, Socket Mounting Kit, Mounting Kit

References

-  [SilverStone](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.