

# **SUPER73 Folding Static Pegs Instructions**

**Home** » **SUPER73** » **SUPER73** Folding Static Pegs Instructions

#### **Contents**

1 SUPER73 Folding Static

Peg:

- **2 Product Usage Instructions**
- **3 STATIC PEGS**

**INSTALLATION** 

- 4 Documents / Resources
  - 4.1 References
- **5 Related Posts**

# **SUPER73**



#### **Product Information**

# **Specifications**

• Product Name: Static Pegs

• Compatibility: Bike models with peg attachment holes near the rear wheel

• Materials: Metal

• Weight: N/A

• Color: N/A

# **Product Usage Instructions**

# 1. Step 1: Bike Preparation

Ensure that the bike is stable and turned off.

# 2. Step 2: Locating Peg Attachment Holes

Locate the peg attachment holes on each side of the bike frame near the rear wheel.

3. Step 3: Attaching the Static Pegs

Take one socket head screw and slide a flat washer onto it.

Insert the screw into one of the peg holes from the inside of the frame.

#### 4. Step 4: Aligning and Tightening

Ensure that all components are aligned properly.

Use a 0 mm hex wrench to tighten the peg into place securely.

#### 5. Step 5: Repeat for the Other Footpeg

Repeat steps 4 to 7 for the other footpeg.

#### Frequently Asked Questions (FAQ)

#### · Q: Where can I find additional support?

A: For further assistance, you can visit our support website at <a href="support.super73.com">support.super73.com</a>.

#### STATIC PEGS INSTALLATION

#### Caution

- The peg attachment is located near the rear brake rotor. DO NOT install immediately after riding as the brake rotor will be hot and could potentially burn you.
- When using footpegs, refer to your bike's user handbook and do not exceed the maximum recommended weight limit for your bike of 325 lbs.
- Avoid touching the brake rotor during installation as the oils on your hand will contaminate the rotor and cause
  it to squeak when in use.

#### **Included Materials**

- Static Peg (x2)
- Anti-Rotation Bracket (x2)
- Socket Head Screw- M<sup>2</sup> x <sup>2</sup>.25mm Thread, 20mm Long (x2)
- 18-8 Stainless Steel Washers for M<sup>2</sup> Screw Size, <sup>3mm</sup> ID, 20mm OD (x2)

#### **Tools Required**

10mm Hex Wrench

#### **Installation Instructions**

- 1. Start with the bike stable and turn it off. Locate the peg attachment holes on each side of the frame near the rear wheel.
- 2. Slide one flat washer onto one of the socket head screws then insert the screw into the peg hole from the inside of the frame.
- 3. Hold the washer and bolt in the hole, feed the following components onto the screw in this order
  - 1. 1 anti-rotation bracket with the tab positioned under the attachment hole.
  - 2. Flat washer
  - 3. The footpage can be installed and hand-tightened until the hex wrench is needed.
- 4. Now that all of the components are aligned, use the ~0 mm hex wrench to tighten the peg into place.

# **Documents / Resources**



**SUPER73 Folding Static Pegs** [pdf] Instructions

Folding Static Pegs, Static Pegs, Pegs

### References

• User Manual

Manuals+, Privacy Policy