

**Contents** [[hide](#)][1 CCD-0009186 MTF Hardtop Shade](#)[1.1 SureShade M3 Measuring Instructions for Hardtop](#)[1.2 SUMMARY](#)[1.3 STEP 4: DETERMINE IF MOUNTING SPACERS ARE REQUIRED.](#)[2 Documents / Resources](#)[2.1 References](#)

CCD-0009186 MTF Hardtop Shade



1900 47TH TERRACE EAST, BRADENTON, FL 34203 • Phone: [877-333-8323](tel:877-333-8323) –
International [215-673-2307](tel:215-673-2307) • www.sureshade.com


SureShade M3 Measuring Instructions for Hardtop

SUMMARY

- **STEP 1:** Determine mounting area (underside or topside) based on M3 shade space requirements
- **STEP 2:** Determine shade width
- **STEP 3:** Determine if a camber to the shade's cross-components (crossbars and roller) is needed
- **STEP 4:** Determine if mounting spacers are required

STEP 1: DETERMINE MOUNTING AREA (underside or topside) based on M3 shade

space requirements. The M3 shade extends up to 10 ft (3048 mm). The stationary tube length dimensions are found below. Shade width and crossbar camber (if any) are customized to client specification



STEP 2: DETERMINE SHADE WIDTH. M3 framework (stationary actuator) and mounting clamps require an obstruction free area shown below.

M3 shade width is specified by the “outside to outside” tube dimension – outside of PORT actuator to outside of STBD actuator. The maximum possible width for an M3 shade is 144” (3658 mm).

Once required space is determined for shade framework, measure and provide the OUTSIDE to OUTSIDE width dimension.

CCD-0009186 Rev: 05.28.2025

STEP 3: DETERMINE CAMBER HEIGHT. The M3 shade’s cross-components—the outer crossbar, two mid crossbars, and canvas roller—can be cambered (curved) to conform to the curvature of the hardtop. Determine if the hardtop has curvature and if camber is desired.



For bottom mounted shades, once width is determined,

(1) Position a straight edge across the bottom of the hardtop.

1. Position a straight edge across the bottom of the hardtop.

2. Measure straight up from the center of the determined width to the underside of the hardtop.

(2) Measure straight up from the center of the determined width to underside of the hardtop.

(3) Provide the camber height dimension in inches or mm.

1. Position a straight edge across the top of the hardtop.



2. Measure straight up from the center of the determined width to the underside of the hardtop.


For top mounted shades, once width is determined,

(1) Position a straight edge across the topside of the hardtop.

(2) Measure from the straight edge to where the actuator will mount.

(3) Provide the camber height dimension in inches or mm.

STEP 4: DETERMINE IF MOUNTING SPACERS ARE REQUIRED.



Spacers are used to allow the shade to clear the overhang (or lip) of the hardtop or other obstructions like rod holders. SureShade can supply a spacer that fits in between the mounting clamp and the mounting plate in $\frac{1}{2}$ " (12.7 mm) increments up to 3" (76 mm). The shade framework is 5" (127 mm) tall. Measure the height of any overhang (lip) or obstruction in the path of the framework. Round the measurement up to the nearest $\frac{1}{2}$ " (12.7 mm) to determine the height of the spacer required.

In this example, Mount 1 requires a spacer to keep the actuator parallel with the second step of the hardtop. A spacer is not needed for Mount 2.



05.28.2025

PLEASE SUBMIT YOUR MEASUREMENTS

ONLINE <https://www.sureshade.com/measure/> If you prefer- please email the completed sheet to sales@sureshade.com or directly to your sales representative.

Shade Specifications	
Customer	
Boat Year/Make/Model	
Commercial Ship to Address	
Shade Type	M3 – Automatic
Extension Length	10 FT
Mounting Component	Standard
Roller Placement	Stationary
Canvas Color	

Placement (top or bottom mount)	
Outside-to-Outside Tube Width (inches or mm)	
Measured Camber Height (inches or mm)	
Measured Spacer Height (½ inch [12.7 mm] increment)	
Motor Type (12V or 24V)	
Control Wire Length (feet or mm)	

DISCLAIMER: All shades are made to custom specifications. Ensure all measurements are accurate before sending them to your customer service representative. Any errors made by the customer are the customer's responsibility.

Documents / Resources



[SURESHADE CCD-0009186 MTF Hardtop Shade \[pdf\]](#) Instruction Manua

I

CCD-0009186 MTF Hardtop Shade, CCD-0009186, MTF Hardtop Shade, Hardtop Shade, Shade

References

- [User Manual](#)

■ SURESHADE

◆ CCD-0009186, CCD-0009186 MTF Hardtop Shade, Hardtop Shade, MTF Hardtop Shade, Shade, SURESHADE

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.