

ULINE Anti-Static Table Mat Installation Guide

Home » ULINE » ULINE Anti-Static Table Mat Installation Guide 1



Contents

- 1 INSTALLATION
- 2 Contact Us
- 3 Documents /
- Resources
- **4 Related Posts**


INSTALLATION

- 1. Fasten the ground cord to the most convenient snap fastener.
- 2. Unwind just enough ground cord to reach a suitable building ground. A ground cord can be fastened to a grounded wall outlet first by shutting off the power to such outlet and then removing the cover plate and

attaching to one of the screws holding the receptacle box. Remove only one screw.

NOTE: Do not remove receptacle from the box. For personnel unfamiliar with making electrical connections, it is recommended that the ground connections be done by an electrician.

- 3. It is important to make proper ground connections to prevent personal shock in the unlikely event that the mat is accidentally electrified. Use only cords supplied with the mat. Take care not to short-circuit the ground cord or floor mat by bringing the mat into contact with a hard ground.
- 4. Installation is now complete.



Contact Us

Phone: 800-295-5510 **Web:** <u>uline.com</u>



Documents / Resources



Manuals+,