



VERSATRAX L Series Track Tie Down Anchor Rails Installation Guide

[Home](#) » [VERSATRAX](#) » VERSATRAX L Series Track Tie Down Anchor Rails Installation Guide 

VERSATRAX

L-Series Track Tie-Down
Anchor Rails
Install Instructions



Contents

- [1 Parts Included:](#)
- [2 Documents / Resources](#)
- [2.1 References](#)

Parts Included:

- (2) or (4) L-Series Track Anchor Rails (option dependent)
- (4) or (8) L-Series Single Stud L-Series Anchor Fittings
- (4) RailTrax Bolts (Tundra only)
- (1) TP50 (Torx Plus 50) 3/8" Drive (Tundra only)

Step 1: Remove the OEM bed bolts utilizing a T55 (Torx 55) drive (see photo 1).

Note: OEM bed bolts that are covered in bed liner will need to be cut around the flange/washer to remove. Rest assured, the tracks will cover the exposed bed when installed.

Step 2: Position each rail between the bed bolt holes. (see photo 2).


Step 3: Install the bolts through each slot on the rails and secure directly to the frame of the vehicle.

Step 4: Torque each bolt to 50 ft/lb.

Note: Parts/positions being referenced are highlighted in blue in the photos.

VERSATRAX

Documents / Resources

	<p>VERSATRAX L Series Track Tie Down Anchor Rails [pdf] Installation Guide</p> <p>L Series Track Tie Down Anchor Rails, L Series, Track Tie Down Anchor Rails, Tie Down Anchor Rails, Down Anchor Rails, Anchor Rails, Rails</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.