

# **Wickes S3308 General Purpose Spruce Cladding Instructions**

Home » Wickes » Wickes S3308 General Purpose Spruce Cladding Instructions



## Wickes S3308 General Purpose Spruce



#### **Contents**

- 1 Fixing Instructions
- **2 IMPORTANT**
- 3 Documents /

**Resources** 

- 3.1 References
- **4 Related Posts**

## **Fixing Instructions**

- 1. Open pack(s) and store flat in a pile for a minimum of 72 hours in the room in which they are going to be used. Shuffle the pile daily to ensure that all boards adapt to room conditions.
- 2. Fit Cladding battens around the perimeter of the area to be clad. Then fill in with further cladding battens spaced at maximum centres of 400mm and running at 900 to the cladding.
- 3. Fix each piece of the cladding to every cladding batten with either clips or panel pins.

#### **IMPORTANT**

- Traditional Cladding must be sealed immediately to avoid moisture absorption.
- Use wood varnish, wood stain or paint suitable for timber.
- Only fix with cladding clips or panel pins Do not use adhesives.
- Do not fix in recently plastered rooms because of the high moisture content.
- Please ensure the ends are treated / sealed to prevent moisture ingress.

### **Documents / Resources**



Wickes S3308 General Purpose Spruce Cladding [pdf] Instructions

S3308, S3308 General Purpose Spruce Cladding, General Purpose Spruce Cladding, Purpose Spruce Cladding, Spruce Cladding, Cladding

## References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.