Home » 360Tronics » 360Tronics B082BKJ2NK Computer Tower Stand CPU Tower Cart Instruction Manual

# **360Tronics B082BKJ2NK Computer Tower Stand CPU Tower Cart Instruction Manual**



### **Contents**

- 1 Computer Tower Stand
- 2 Documents /


Resources

2.1 References

## **Computer Tower Stand**



Load-bearing 90LBS (40.8KG)




Black Oak White Walnut




910-882-9205 360tronixIIc@gmail.com | www.360Tronix.com 2978 Gillespie Street, Unit 101, Fayetteville, NC 28306


Copyrights Reserved by 360Tronics, a Trademark owned by 360 LED, LLC.



- (A) Carbon Steel Frame x 2
- (B) Particle Board (side) x 1
- (C) Particle Board (up + down) x 2
- (D) Metal Swivel Casters x 4
- (E) Installation Screws x 14
- (F) Hex Wrench x 1
- (G) Wrench Tool x 1
- (1) Install the four metal swivel casters(D) into the carbon steel frame (A).



(2) Tighten all the screws to a moderately snug state, and then proceed to tighten all the screws after confirming that there are no issues in any position.



# (3) Installation completed.





Scan QR to watch the box open video



Scan QR to watch the installation video (Sample of Black.)



360Tronics B082BKJ2NK Computer Tower Stand CPU Tower Cart [pdf] Instruction Manual B082BKJ2NK Computer Tower Stand CPU Tower Cart, B082BKJ2NK, Computer Tower Stand CPU Tower Cart, Tower Stand CPU Tower Cart, Stand CPU Tower Cart, CPU Tower Cart

## References

User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.