

3xLOGIC Allegion Engage S Gateway User Guide

Home » 3xLOGIC » 3xLOGIC Allegion Engage S Gateway User Guide 1

Contents

- 1 3xLOGIC Allegion Engage S Gateway
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Allegion ENGAGE-S Gateway Quick StartGuide
- StartGuide
- 5 Before You Begin
- **6 INFINIAS Setup**
- 7 ENGAGE Gateway and Lock Setup
- 8 Link Lock Gateway
- 9 Installation Video
- **10 Contact Information**
- 11 FAQ
- 12 Documents / Resources
 - 12.1 References



3xLOGIC Allegion Engage S Gateway



Product Information

Specifications

Product Name: S-Engage-Gateway

• Model: S-ENGAGE-GATEWAY

• Compatibility: Apple or Android mobile devices with Bluetooth

• Software Requirement: infinias CLOUD or Server version 6.4 or above

Product Usage Instructions

- This guide is for setting up Allegion LE and NDE model wireless door locks in INFINIAS software. Prior to configuration, ensure you have:
- An Apple or Android mobile device with Bluetooth.
- The ENGAGE Mobile App was installed.
- An ENGAGE Gateway, model S-ENGAGE-GATEWAY.
- License per wireless lock S-WL-1.
- INFINIAS CLOUD or Server version 6.4 or above.
- Installed the physical lock (LE or NDE models); used a QR code scanner to view installation videos.
- Install the activation license from 3xLOGIC in the INFINIAS server software.
- Create a user account at https://portal.allegionengage.com/signup.
- Program API settings for a local server install only in INFINIAS; the Allegion site must be created by INFINIAS.
- Edit a Customer to enable Allegion integration and specify the Weigand format and Serial Number of your ENGAGE Gateway.
- Navigate to the Door Types view under the Settings tab within Configuration to enable the ENGAGE Fail Safe 5-Second Unlock and the ENGAGE Fail Secure 5-Second Unlock.

COPYRIGHT AND LEGAL NOTICES | 3XLOGIC | QUICK START GUIDE

• INFINIAS Copyright ©2025 3xLOGIC, Inc. All rights reserved.

3xLOGIC Inc

• 11899 Exit 5 Parkway, Suite 100Fishers, IN 46037United States. 303-430-1969

Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of 3xLOGIC Inc.
- The software and/or databases described in this document are furnished under a license agreement or nondisclosure agreement.
- They may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software on any medium except as specifically allowed in the license or nondisclosure agreement.
- The purchaser may make one copy of the software for backup purposes. No part of this manual and/or
 databases may be reproduced or transmitted in any form or by any means, electronic or mechanical, including
 (but not limited to) photocopying, recording, or information storage and retrieval systems, for any purpose other
 than the purchaser's personal use, without the express written permission of 3xLOGIC Inc.
- 3xLOGIC & INFINIAS are trademarks of 3xLOGIC, Inc.
- Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. 3xLOGIC Inc. disclaims any proprietary interest in trademarks and trade names other than their own.

Allegion ENGAGE-S Gateway Quick StartGuide

 These are the instructions for the setup of Allegion LE and NDE model wireless door locks in INFINIAS software.

Before You Begin

This guide is abridged for users already familiar with the ENGAGE install. For more detailed instruc-tions, please reference the linked video (QR Code) at the end of this guide..

The following items are required prior to configuring the integration:

- 1. An Apple or Android mobile device with Bluetooth.
- 2. The ENGAGE Mobile App was installed.
- 3. An ENGAGE Gateway, model S-ENGAGE-GATEWAY.
- 4. License per wireless lock S-WL-1.
- 5. INFINIAS CLOUD or Server version 6.4 or above (ESSENTIALS, CORPORATE, PROFESSIONAL).
- 6. Install the physical lock (LE or NDE models); use a QR code scanner to view installation videos for the associated for the applicable model.









Pre-configuration Requirements

- 1. Install the activation license from 3xLOGIC in the INFINIAS server software.
- 2. Visit https://portal.allegionengage.com/signup to create a user account.
- 3. Program API settings *for local server install only in INFINIAS.* The Allegion site must be created by INFINIAS.

INFINIAS Setup

- 1. Edit a Customer to enable Allegion integration, and specify the Weigand format and the SerialNumber of your ENGAGE Gateway.
- 2. Navigate to the Door Types view under the Settings tab within Configuration to enable the ENGAGE Fail Safe 5-Second Unlock and the ENGAGE Fail Secure 5 Second Unlock.

ENGAGE Gateway and Lock Setup

- 1. Connect the gateway to a Power Over Ethernet switch.
 - If using a standard switch, use the supplied AC cable to power the gateway.
- 2. Download and install the ENGAGE Mobile App.
- 3. Login to the ENGAGE Mobile App with the previously created account.
- 4. Select the desired Customer Name (customer name will auto-populate from INFINIAS), and click the + sign to add a "Gateway" to the list.
- 5. Select the IP Tab; choose IP Behind Firewall; then select Next.
- 6. Enter the following information:
 - Local Server Access Control
 - Server URL:https://[SERVER IP ADDRESS]:19800
 - Certificate Authority (CA) Server URL:http://[SERVER IP ADDRESS]/web has/engage
 - · Cloud-based Access Control
 - Server URL: https://devices.ia.3xlogic.com:19800
 - CA Server URL: http://devices.ia.3xlogic.com/webhal/engage

Link Lock Gateway

- 1. In the ENGAGE App, Select the Customer Name to which you want to associate the lock.
- 2. Click the + sign to select the applicable model of the lock.
- 3. Return to the Device Selection Screen and select Managed Linked Devices.
- 4. Link your wireless lock to the gateway.

Add Lock to INFINIAS

- 1. In the INFINIAS software, Select Create Door action under Configuration, select AllegionENGAGE, and fill out the door details.
- 2. Select the lock that was previously configured under Serial Number.

Installation Video

• Scan the QR code for a step-by-step video for comprehensive ENGAGE Gateway Installation.



Contact Information

- 3xLOGIC has offices in Victoria BC, Canada, and in Fishers, Indiana, USA.
- Please visit our 3xLOGIC website at <u>www.3xlogic.com</u>. Please contact us by e-mail at <u>helpdesk@3xlogic.com</u> (technical support), or using the following contact information:

3xLOGIC Technical Support

Toll Free:(877) 3XLOGIC (877)395-6442Email: helpdesk@3xlogic.com.Website: www.3xlogic.com

3xLOGIC USA Main Office

- 11899 Exit 5 Parkway, Suite 100Fishers, IN 46037United States. 303-430-1969
- ©2025 3xLOGIC Inc.
- www.3xlogic.com
- helpdesk@3xlogic.com

FAQ

- Q: How do I link my wireless lock to the gateway?
- A: To link your wireless lock to the gateway, follow these steps:
 - In the ENGAGE App, select the Customer Name to which you want to associate the lock.
 - Click the + sign to select the applicable model of the lock.
 - Return to the Device Selection Screen and select Managed Linked Devices.
 - Link your wireless lock to the gateway.

Documents / Resources



3xLOGIC Allegion Engage S Gateway [pdf] User Guide S-ENGAGE-GATEWAY, Allegion Engage S Gateway, Allegion, Engage S Gateway, Gateway

References

- 3x Video, Business Intelligence & Access Control Solutions | 3xLOGIC
- 3x Video, Business Intelligence & Access Control Solutions | 3xLOGIC

- Engage Technology by Allegion
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.