



8BitDo SN30 Pro USB Gamepad User Manual


[Home](#) » [8Bitdo](#) » 8BitDo SN30 Pro USB Gamepad User Manual

Contents [[hide](#)]

- [1 8BitDo SN30 Pro USB Gamepad User Manual](#)
- [2 SN30 Pro USB Gamepad Instruction](#)
- [3 Switch](#)
- [4 Windows \(X – input\)](#)
- [5 Turbo Function](#)
- [6 Support](#)
- [7 FAQ – Frequently Asked Question](#)
- [8 Download](#)
- [9 Related Posts](#)

8BitDo SN30 Pro USB Gamepad User Manual





Switch

1. Connect SN30 Pro USB controller to your Switch dock via the USB cable

- Switch system version 3.0.0 or above
- Turn on 'Pro Controller Wired Communication'

Windows (X – input)

1. Connect SN30 Pro USB controller to your Windows device via the USB cable

- Windows 7 or above

Turbo Function

1. Hold the button you would like to set turbo functionality to and press the STAR button to activate/deactivate turbo functionality
2. LED on the right will blink when the button with turbo function is pressed

- STAR button = Switch screenshot button on Switch mode

Support

- Please visit support.8bitdo.com for further information & additional support

FAQ – Frequently Asked Question

What is the difference between SN30 Pro USB and SN30 Pro Bluetooth?

The differences are:

A. Connectivity

SN30 Pro USB: wired USB connection only.

SN30 Pro Bluetooth: both wireless Bluetooth connection and USB wired connection.

B. Compatibility

SN30 Pro USB: Switch, Windows 10 and Raspberry Pi.

SN30 Pro Bluetooth: Switch, Windows 10, Raspberry Pi, Android and macOS.

C. Motion controls

SN30 Pro USB: N/A.

SN30 Pro Bluetooth: Yes.

How long is the USB cable?

1.8 meters.

Can I use it with my PlayStation Classic Edition?

No, you can not.

Does this controller have vibration and motion controls?

It has vibration but not motion controls.

Can I use it with an Android device with an adapter?

Yes, however, the device needs to have USB OTG and be version 9.0 Pie and above. Any version below 9.0 (Pie) may not work.

Does this controller have Screenshot, Home and Turbo buttons when connected to Switch? Can I also wake up my Switch with it? Additionally, does it have NFC function?

When connected to Switch, you can find on this controller:

A. Screenshot = STAR button

B. Home button = Logo button

Turbo and NFC functions are not applicable here. You can not wake up your Switch it.

When connected to Windows 10, you can set Turbo function to any of the face buttons as well as L & R buttons.

STAR button will blink when the button with this function is pressed.

Can I remap A/B/X/Y buttons on when the controller is on its X-input mode?

No, you can not.

Download

8BitDo SN30 Pro USB Gamepad User Manual – [[Download PDF](#)]
