




8BitDo M30 Wired Controller Instruction Manual

[Home](#) » [8Bitdo](#) » 8BitDo M30 Wired Controller Instruction Manual 

8BitDo M30 Wired Controller Instruction Manual

8BitDo[®]

M30 Wired Controller for Xbox




Contents

- [1 Xbox Series X|S or Xbox One](#)
- [2 Windows 10 / Windows 11](#)
- [3 Volume Control](#)
- [4 Ultimate Software](#)
- [5 Support](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

* The latest firmware version of your Xbox console is required.


Connect the controller to your Xbox console via its USB cable, and wait till the status LED becomes solid to play.



Windows 10 / Windows 11

* System requirement: Windows 10(1903) or above.


Connect the controller to your Windows device via its USB cable, and wait till the status LED becomes solid to play.




Volume Control

* Emits a beep when adjusted to maximum, middle, or minimum value.

* Press and hold profile+ up/down to turn up/down in-game volume.



* Press and hold **profile + left/right** to adjust the balance between voice and game volume.



Ultimate Software


* Press the profile button to activate/deactivate the custom profile. The profile indicator will not light up when using the default setting.

* Please visit app.8bitdo.com for 8BitDo Ultimate Software X, which gives you elite control over every piece of your controller.

Support

Please visit support.8bitdo.com for further information & additional support.

Documents / Resources



[8BitDo M30 Wired Controller](#) [pdf] Instruction Manual
M30 Wired Controller, M30, Wired Controller, Controller

References

- [User Manual](#)

