



## 8BitDo NEOGEO Wireless Controller User Manual

[Home](#) » [8Bitdo](#) » 8BitDo NEOGEO Wireless Controller User Manual 


### 8BitDo NEOGEO Wireless Controller



#### Contents

- [1 Product Description](#)
- [2 NEOGEO mini](#)
  - [2.1 wireless connection](#)
  - [2.2 wired connection](#)
- [3 Windows](#)
  - [3.1 wireless connection](#)
- [4 wired connection](#)
- [5 Android](#)
  - [5.1 Bluetooth connection](#)
- [6 D-Pad Switch](#)
- [7 Re-pairing with the adapter](#)
- [8 Battery](#)
- [9 Support](#)
- [10 Documents / Resources](#)

### Product Description



## 2.4G Adapter



- press start button to turn on the controller
- hold start button for 3 seconds to turn off the controller
- hold start button for 8 seconds to force the controller off

## NEOGEO mini

- press and hold select + down to switch the button layout. The Power LED will blink once when switching, and it will be saved automatically

## wireless connection

1. connect the 2.4G adapter to the controller port of your NEOGEO mini console
2. turn the mode switch to 2.4G
3. press the start button to turn on the controller, the status LED becomes solid when the connection is successful

#### **wired connection**

1. connect the controller to the controller port of the NEOGEO mini via the USB cable
2. wait till the controller is successfully recognized by your NEOGEO mini to play

### **Windows**

- required system: Windows 10 (1903) or above

#### **wireless connection**

1. connect the 2.4G adapter to the USB port of your Windows device
2. turn the mode switch to 2.4G
3. press the start button to turn on the controller, the status LED becomes solid when the connection is successful

#### **wired connection**

1. connect the controller to the USB port of the Windows device via the USB cable
2. wait till the controller is successfully recognized by your Windows to play

### **Android**

required system: Android 9.0 or above

#### **Bluetooth connection**

1. turn the mode switch to Bluetooth
2. press the pair button to enter its pairing mode, the status LED starts to rotate from left to right. (this is required for the very first time only)
3. go to your Android device's Bluetooth setting, pair with [ 8BitDo NEOGEO GP ], the status LED becomes solid when the connection is successful

### **D-Pad Switch**

- press the button combos below for 5 seconds to switch the D-Pad, the Power LED will blink once when switching
- select + up = D-Pad
- select + left = Left Stick
- select + right = Right Stick
- it will be saved automatically after switching
- this function is not available when connected to NEOGEO mini

## Re-pairing with the adapter

- please follow the steps below to re-pair the controller with the adapter
  1. connect the 2.4G adapter to the NEOGEO mini or Windows device
  2. turn the mode switch to 2.4G
  3. press start button to turn on the controller
  4. hold the pair button to enter its pairing mode, the status LED starts to rotate from left to right
  5. put the controller close to the 2.4G adapter, the status LED becomes solid when the connection is successful
- each receiver can only be paired with one controller

## Battery

**status** LED indicator

**low battery mode** red LED blinks

**low battery mode** red LED stays solid

**battery charged** red LED turns off

- 50 hours of play time via Bluetooth and 35 hours via wireless 2.4G with a 300mAh built-in battery pack, rechargeable with 1 hour charging time
- controller will turn off in 1 minute with no connection or 15 minutes of inactivity when connected with Bluetooth or 2.4G
- controller stays on with wired connection

## Support

- please visit [support.8bitdo.com](https://support.8bitdo.com) for further information & additional support



## Documents / Resources



[8BitDo NEOGEO Wireless Controller](#) [pdf] User Manual  
NEOGEO Wireless Controller, NEOGEO, Wireless Controller, Controller