



8BitDo Pro 2 Wired Gamepad/Controller Instruction Manual

[Home](#) » [8Bitdo](#) » 8BitDo Pro 2 Wired Gamepad/Controller Instruction Manual 

Contents


- [1 8BitDo Pro 2 Wired Gamepad/Controller](#)
- [2 Pro 2 Wired gamepad – instruction manual](#)
- [3 Switch](#)
- [4 Windows CX – input\)](#)
- [5 Android](#)
- [6 Turbo function](#)
- [7 Ultimate Software](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

8BitDo[®]

8BitDo Pro 2 Wired Gamepad/Controller



Pro 2 Wired gamepad – instruction manual



Switch

- Switch system needs to be 3.0.0 or above for wired connection. Go to System Setting> Controller and Sensors> turn on Pro Controller Wired Communication
- NFC scanning, IR camera, HD rumble, motion controls, notification LED are not supported, nor can the system be waken up
- LED lights indicate the player number, 1 LED indicates player 1, 2 LEDs indicate player 2, 4 is the maximum number of players the controller supports
 - connect the controller to your Switch dock via its USB cable
 - wait till the controller is successfully recognized by your Switch to play

Windows CX – input)

- required system: Windows 10 (1703) or above
- LED lights indicate the player number, 1 LED indicates player 1, 2 LEDs indicate player 2, 4 is the maximum number of players the controller supports
 - connect the controller to your Windows device via its USB cable
 - wait till the controller is successfully recognized by your Windows device to play

Android

- required system: Android 9.0 or above

- TG support is required on your Android device
 - hold B button, then connect the controller to your Android device via it USB cable
 - wait till the controller is successfully recognized by your Android device to play

Turbo function

1. hold the button you would like to set turbo functionality to and then press the star button to activate its turbo functionality
2. Home LED blinks continuously when the button with turbo functionality is pressed
3. Hold the button with turbo functionality then press star to deactivate its turbo functionality. Home LED stops blinking
4. padjoysticks, home, select and start buttons are not included


Ultimate Software

- 8BitDo Ultimate Software gives you elite control over every piece of your controller: customize button mapping, adjust stick & trigger sensitivity, control vibration power and create macros with any button combination
- e.g. create macros and more with P1, P2
- please visit support.8bitdo.com for the application
- press profile switch button to switch between 3 custom profiles. The profile indicator will not light up when using the default setting

support

- please visit support.8bitdo.com for further information & additional support

Documents / Resources

	<p>8BitDo Pro 2 Wired Gamepad/Controller [pdf] Instruction Manual Pro 2, Wired Gamepad Controller, Pro 2 Wired Gamepad Controller</p>
---	---