

2N 382210 IP Force Vandal Resistant Door Intercom Unit



2N 382210 IP Force Vandal Resistant Door Intercom Unit Instruction Manual

[Home](#) » [2N](#) » 2N 382210 IP Force Vandal Resistant Door Intercom Unit Instruction Manual 

Contents

- [1 2N 382210 IP Force Vandal Resistant Door Intercom Unit](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 IP Force Installation Accessories](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

2N

2N 382210 IP Force Vandal Resistant Door Intercom Unit



Product Information

Specifications

- **Product Name:** 2N IP Force Series
- **Type:** IP Force Vandal Resistant Door Intercom Unit

Product Usage Instructions

Installation

To install the IP Force Vandal Resistant Door Intercom Unit, follow these steps:

1. Choose the appropriate mounting post from the IP Force Installation Accessories list.
2. Make sure the mounting post is securely fixed in the desired location.
3. Attach the intercom unit to the mounting plate of the chosen post.
4. Connect the necessary cables according to the provided installation guide.
5. Power on the intercom unit and configure the settings as needed.

Maintenance

Regular maintenance of the intercom unit is essential for optimal performance.

Follow these maintenance tips:

- Clean the unit regularly with a soft, damp cloth to remove dust and dirt.
- Check for any loose connections or signs of wear and tear.
- Test the functionality of the intercom system periodically.

Troubleshooting

If you encounter any issues with the IP Force Vandal Resistant Door Intercom Unit, refer to the troubleshooting section of the user manual. Common issues and solutions are provided to help you resolve problems quickly.

FAQ

Q: Can the IP Force Vandal Resistant Door Intercom Unit be used with other intercom brands?

A: The unit is designed for use with the 2N range of Force and Safety intercoms; however, with modifications to the mounting plate, it can also be compatible with other 2N and Akuvox Intercoms.

IP Force Installation Accessories

9151005 Single Height Gooseneck Intercom Stand – Car Height

- Designed for use with the 2N range of Force and Safety intercoms; however, this mounting post can also be used with other 2N and Akuvox Intercoms with modifications to the intercom unit's mounting plate.



382210 Single Height Gooseneck Intercom Stand – Car Height

- Car height intercom stands for access control keypads, readers and door entry panels. Finished in black to complement the gate and other access areas.



382220 Dual Height Gooseneck Intercom Stand – Car & Lorry Height

- Dual height mounting post ideal for mounting access control keypads, readers and door entry panels at entrances to lorry parks, distribution centres, or logistics zones.



9151007 Dual Height Gooseneck Intercom Stand – Car & Lorry Height

- Designed for use with the 2N range of Force and Safety intercoms; however, this mounting post can also be used with other 2N and Akuvox Intercoms with modifications to the intercom unit's mounting plate.



Find out more:



Documents / Resources



[2N 382210 IP Force Vandal Resistant Door Intercom Unit](#) [pdf] Instruction Manual
382210 IP Force Vandal Resistant Door Intercom Unit, 382210, IP Force Vandal Resistant Door Intercom Unit, Vandal Resistant Door Intercom Unit, Resistant Door Intercom Unit, Door Intercom Unit, Intercom Unit, Unit

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.