



[Home](#) » [DW](#) » **DW DWC-XSBC08BiC1 4K bullet IP camera with Ai User Guide** 

## Contents [ [hide](#) ]

- 1 DW DWC-XSBC08BiC1 4K bullet IP camera with Ai
- 2 WHAT'S IN THE BOX
- 3 SAFETY AND WARNING INFORMATION
- 4 PREPARING TO MOUNT THE CAMERA
- 5 POWERING THE CAMERA
- 6 WATERPROOF CAP INSTALLATION
- 7 INSTALLING THE CAMERA
- 8 CABLING
- 9 DW® IP FINDER™
- 10 WEB VIEWER
- 11 FAQ
- 12 Documents / Resources
  - 12.1 References



**DW DWC-XSBC08BiC1 4K bullet IP camera with Ai**



## WHAT'S IN THE BOX

WHAT'S IN THE BOX					
Quick Setup and Download Guide		1	Screws and Plastic Anchors - 4pcs		1 set
Mounting Template		1	Star Wrench (T10, T20)		1
Test Video Cable		1	Moisture Absorber and Guide (Recommended)		1 set
Waterproof Cap and Rubber Rings (Black: ø0.15" (ø4mm), White: ø0.19" (ø5mm))		1 set			

**NOTE:** Download all your support materials and tools in one place

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the 'Search by Product' search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click 'Search'. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



Attention: This document is intended to serve as a quick reference for the initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage.

## **SAFETY AND WARNING INFORMATION**

Read through this Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. See the user manual for more information on the proper installation, use and care of the product.

These instructions are intended to ensure that users can use the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected.

Cautions: Injury or equipment damage may occur if any of the cautions are neglected.

### **WARNING**

1. In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.
2. Be sure to use only the standard adapter specified in the specification sheet. Using any other adapter could cause fire, electrical shock, or damage to the product.
3. Make sure the power supply voltage is correct before using the camera.
4. Incorrectly connecting the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product.
5. Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat generation or fire.

6. Securely plug the power cord into the power source. An insecure connection may cause a fire.
7. When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.
8. Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or electric shock.
9. Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.
10. Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.
11. Do not install near any heat sources such as radiators, heat registers, or other products (including amplifiers) that produce heat.
12. Keep out of direct sunlight and heat radiation sources. It may cause a fire.
13. If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock.
14. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.
15. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.

## **CAUTION**

1. Use proper safety gear when installing and wiring the product.
2. Do not drop objects on the product or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference.
3. Do not use this product near water.
4. The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product.
5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor.
6. The Main plug is used as a disconnect device and shall stay readily operable at any time.


7. Remove the power adapter from the outlet when then there is lightning. Neglecting to do so may cause fire or damage to the product.
8. Do not block any ventilation openings. Install following the manufacturer's instructions.
9. A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
11. If any laser equipment is used near the product, make sure the surface of the sensor is not exposed to the laser beam as that may damage the sensor module.
12. If you want to move the already installed product, be sure to turn off the power and then move or reinstall it.
13. Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.
14. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
15. Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.
16. Use only attachments/accessories specified by the manufacturer.
17. Always use hardware (e.g. screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount.
18. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product.
19. Unplug this product when a cart is used. Use caution when moving the cart/product combination to avoid injury from tip-over.
20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

## STEP 1 –

### PREPARING TO MOUNT THE CAMERA

#### 1. Install the Dessicant Pack (moisture absorber):

- Remove the Dessicant Pack from its shipping packaging. Fold the moisture absorber pack diagonally along the dotted line in the diagram below.
- Open the camera's control panel on the side of the camera.
- Remove the Dessicant Pack used for shipping and place the new Dessicant Pack in the location shown in the illustration below.
- Close the camera control panel tightly.




NOTE: The camera will generate enough heat to dry moisture during normal operation. In cases where the camera experiences a moisture issue, keep the moisture absorber in the camera.

WARNING: Install the moisture absorber when mounting the camera to prevent image performance issues and damage to the camera.

#### 2. Using the mounting template sheet or the camera itself, mark and drill the necessary holes in the wall or ceiling.

**Resetting the camera:** Use the tip of a paper clip or a pencil and press the reset button for five (5) seconds to initiate a camera-wide reset of all the settings, including network settings.



**STEP 2 –**

**POWERING THE CAMERA**

Pass the wires through and make all necessary connections.

- Use a PoE Injector (required. Sold separately) to connect data and power to the camera using a single Ethernet cable.
- Use non-PoE Switch to connect data using and Ethernet cable and use a power adapter to power the camera.



Power information	
Power requirements	DC12V, PoE (IEEE 802.3af class 3). Adapter not Included.


Power consumption	DC12V: max 21.9W, 1.83A, PoE: max 9.2W, 200mA
Maximum distance	328' (100m)
Connector	RJ45

## WATERPROOF CAP INSTALLATION

The waterproof cap set comes with two rubber rings. Use the rubber ring best sized for your network cable's diameter.

**NOTE:** Cables with  $\varnothing 4.5\text{mm}$  to  $\varnothing 5.5\text{mm}$  thickness should use the black rubber ring. Cables over  $\varnothing 5.5\text{mm}$  in thickness should use the white rubber ring.

- NOTE: To ensure moisture seal, make sure the o-ring d is in place between c and e . In extreme environments use of an outdoor rated sealer is recommended.




### STEP 3 –


## INSTALLING THE CAMERA



1. Secure the camera to the mounting surface using the included screws.
2. Loosen the pan and tilt screw on the camera's bracket to adjust the camera's view and position.



3. Remove the protective film from the lens cover. Softly wipe the lens cover with lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process.




NOTE: Remove the rubber plug on the side of the camera's bracket and use the gap as

a cable guide to prevent cables from getting caught between the camera and the mounting surface.

## STEP 4 –

### CABLING

Use the diagram below to connect power, network and external devices such as audio input and output, alarm and sensors to the camera.



## STEP 5 –

### DW® IP FINDER™

1. Download and install the DW IP Finder from the DW website at: <http://www.digital-watchdog.com>
2. Open the DW IP Finder and click 'Scan Devices' to find the camera on the network.
3. A password must be set when connecting to the camera for the first time.
  - Check the box next to the camera.
  - Click "Bulk Password Assign" on the left.
  - Enter admin/admin for the current username and password. Enter a new

username and password to the right.


Password must have at least eight (8) characters and at least four (4) combinations of uppercase and lowercase letters, numbers and special characters. Passwords cannot contain the user ID.

- Click “change” to apply all changes.



## STEP 6 –

## WEB VIEWER



The GUI display may differ by camera models.

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's view in the results table.
3. Press the 'View Camera Website'.
4. Enter the camera's username and password you set up in the DW IP Finder. If you did not set up a new username and password, a message will direct you to set up a new password for the camera to view the video.

http://192.168.10.159/ - IP Camera - Internet Explorer

## Change admin's password

Password

Retype Password

Password Hint

Password requirement : minimum 8 characters with at least three combinations of uppercase letters, lowercase letters, numbers and special characters.  
Acceptable special characters are; ~ ` ! \$ ^ ( ) \_ - | { } [ ] ; . ? /

## SET UP DW SPECTRUM® CAAS™

To complete the DW Spectrum® CaaS™ server's set up and start recording, see the DW Spectrum® CaaS™ QSG for additional information.

### Default Login Information: admin | admin

When logging into the camera for the first time, you must set up a new password. You can set the new password using the DW® IP Finder™ software or directly from the camera's browser menu.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This products is covered by one or more claims of the HEVC Patents listed at [patentlist.accessadvance.com](http://patentlist.accessadvance.com).

- Tel: +1 [866-446-3595](tel:866-446-3595) / [813-888-9555](tel:813-888-9555)
- Technical Support Hours: 9:00AM – 8:00PM EST, Monday through Friday

Copyright © Digital Watchdog. All rights reserved. Specifications and pricing are subject to change without notice.

- [digital-watchdog.com](http://digital-watchdog.com)

## FAQ

- **Q: Where can I find additional support materials for the product?**


A: You can access all support materials, including manuals and guides, by visiting <http://www.digital-watchdog.com/resources> and searching for your product using the part number.

- **Q: What should I do if the camera is not operating normally?**

A: If the camera is not functioning correctly, stop using it immediately, disconnect the power source, and contact the nearest service center for assistance. Do not attempt to disassemble or modify the product.

## Documents / Resources

--	--



## [WD DWC-XSBC08BiC1 4K bullet IP camera with Ai \[pdf\]](#) User Guide

DWC-XSBC08BiC1, DWC-XSBC08BiC1 4K bullet IP camera with Ai, DW C-XSBC08BiC1, 4K bullet IP camera with Ai, camera with Ai, Ai

## References

- [User Manual](#)

DW

4K bullet IP camera with Ai Ai, camera with Ai, DWC-XSBC08BiC1, DWC-XSBC08BiC1 4K bullet IP camera with Ai, WD

# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.