



GE 93120081 3-Wire Smart Switch Paddle Style Instruction Manual

[Home](#) » [GE](#) » GE 93120081 3-Wire Smart Switch Paddle Style Instruction Manual 

Contents

- [1 GE 93120081 3-Wire Smart Switch Paddle Style](#)
- [2 Try these voice commands](#)
- [3 Touch Controls](#)
- [4 Let's illuminate what your Smart Switch can do](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



GE 93120081 3-Wire Smart Switch Paddle Style



Connect to your or Google Home device to control your lights with your voice. Alexa

Try these voice commands


Amazon Alexa

- Alexa, turn off the living room.
- Alexa, good morning.

Google Home

- Hey Google, turn on the lights.
- Hey Google, I'm leaving.

Touch Controls




Let's illuminate what your Smart Switch can do

1. Create the perfect lighting scene for every occasion.
 - Go to the CYNC App and routines that matches the lighting to your mood.
2. Come home to the lights on at night.
 - Go to the CYNC App. Under scenes create a schedule that turns on your lights at the same time every night.
3. Control other bulbs and devices with your switch.
 - Go to the CYNC App. Add CYNC/ C by GE bulbs, switches and plugs (sold separately) to the same room or group as your switch.

PK-00102809-4

Documents / Resources

	<p>GE 93120081 3-Wire Smart Switch Paddle Style [pdf] Instruction Manual</p> <p>93120081 3-Wire Smart Switch Paddle Style, 93120081, 3-Wire Smart Switch Paddle Style, Smart Switch Paddle Style, Switch Paddle Style, Paddle Style</p>
---	---