


# **HP jump 2 Monitor User Guide**

Home » HP » HP jump 2 Monitor User Guide



## Contents

- 1 Optimum Resolution
- 2 Quick Setup
- 3 Documents /

**Resources** 

- 3.1 References
- **4 Related Posts**

## **Optimum Resolution**

1920 × 1080 @ 60 Hz 1920 × 1200 @ 60 Hz 2560 × 1440 @ 60 Hz

#### Color Side 1:

BLACK + PMS 2925C

#### Color Side 2:

BLACK + PMS 2925C

#### Flat size:


11 x 17 in.

#### Finished size:

5.5 x 5.67 in.


#### Fold 1:

In Half





#### Fold 2:

3-panel accordion



### **Quick Setup**





**WARNING:** To reduce the risk of electric shock, plug the power cord into an AC outlet that is easily accessible at all times. If the power cord has a 3-pin attachment plug, plug the cord into a grounded (earthed) 3-pin outlet.

**WARNING:** To prevent physical injury, do not use this equipment in locations where children are likely to be present.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the web. To access an online copy or order a printed copy of your warranty, go to <a href="http://www.hp.com/go/orderdocuments">http://www.hp.com/go/orderdocuments</a>. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name and your name, phone number, and postal address.



Go to www.hp.com/support to locate your user guide, drivers, and software.



#### **Documents / Resources**



HP HP jump 2 Monitor [pdf] User Guide HSD-0075-W, HSD-0076-W, HSD-0078-W, HP, jump 2, Monitor



**HP HP jump 2 Monitor** [pdf] User Guide HP, jump 2, Monitor

#### References

- Print On Demand process for HP product documents | HP® Support
- mhp.com/support

Manuals+,