

LG PREMTBB10 Standard III Black Wired Remote Controller **User Guide**

Home » LG » LG PREMTBB10 Standard III Black Wired Remote Controller User Guide 🖫



Contents

- 1 LG PREMTBB10 Standard III Black Wired Remote Controller
- 2 LG Standard III Black Wired Remote Controller
- **3 Basic Functions**
- **4 Controller Screen and Buttons**
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**



LG PREMTBB10 Standard III Black Wired Remote Controller



LG Standard III Black Wired Remote Controller

Electrical

Power Supply 12VDC Power From Indoor Unit

Operating Environment

- Operating Temperature 32°F ~104°F (0°C ~ 40°C)
- Storage Temperature -4°F ~ +140°F (-20°C ~ +60°C)
- Humidity 0 ~ 90 % (RH)

Unit Data

- Dimensions 4-3/4" W x 4-3/4" H x 5/8" D
- Mum Number of Indoor Units (per controller) 16
- Maximum Number of Controllers (per Indoor Unit) 2

Connectivity

· LG Communications 1 Channel for V-Net, Wi-Fi with ThinQ Capability

Communications Cable Specifications (V-Net)

- Type Three (3) Conductor (Red: 12V, Yellow: Signal, Black: GND), Stranded, Twisted, Unshielded
- Size AWG 22-3
- · Length2 Up to 164 feet
- AWG American Wire Gauge


Basic Functions

- Room Temperature and Humidity Sensing and Display
- Operation On / Off
- Mode Auto / Cool / Dry / Heat / Fan Only
- · Ventilation Mode (For Ventilator Unit)
- Occupied Cooling and Heating Temperature Setpoint
- Unoccupied Cooling and Heating Setback Temperature Setpoint
- Fan Speed Auto / Low / Med / High
- Discharge Vanes Auto / Swing / Fixed
- · Controller Lock Function
- Static Pressure Installer Setting
- · Error Code Display During Unit or System Malfunction
- · Auto Restart on Power Failure
- Manual Central Control Addressing

Advanced Functions

- Time of Day Scheduling, Five (5) Events per Day with Control of Occupied / Unoccupied, On / Off, Mode,
 Setpoints, and Fan Speed
- Two Setpoint Autochangeover (For Heat Recovery Systems)
- Minimum Difference between Setpoints (0 ~ 10°) Adjustable Dead-band
- Home Leave Function for Temporary Unoccupied Status
- Sub-function Setting
- Comfort Level Display
- External Equipment Control via One (1) Digital Output
- · Filter Sign Check and Initialization
- Time Limit Control (30 minutes ~ 540 minutes, 30-minute units)
- AP Mode Setting for LG Wi-Fi Modem Installation

Controller Screen and Buttons



- 1. Available functions/features may differ based on the connected system.
- 2. Communication cable can be extended to a maximum of 164 feet, between the controller and indoor unit, by using field-supplied wire or the Wired Remote Group Control Cable Assembly (PZCWRCG3) or Wired Remote Extension Cable (PZWRC1), a maximum of four (4).
- 3. Must follow installation instructions in the applicable LG installation manual.
- 4. A centralized controller (AC Smart / ACP Series) and Premium PDI are required for the energy target display function.

Optional Accessories (Sold Separately)

PZCWRC1 – 33-foot Extension Cable Assembly

• PZCWRCG3 – Group Control Cable Kit

Must follow installation instructions in the applicable LG installation manual. For continual product development, LG reserves the right to change specifications without notice.SB_Std_III_Black WiredRemoteController_PREMTBB10_2022_11_03_090947

Documents / Resources



LG PREMTBB10 Standard III Black Wired Remote Controller [pdf] User Guide PREMTBB10 Standard III Black Wired Remote Controller, PREMTBB10, Standard III Black Wired Remote Controller, Remote Controller, Wired Remote Controller

References

• **©** Experience the LG Difference in HVAC - LG Air Conditioning Technologies

Manuals+,