



# RK68 RK855 Wired Mechanical Gaming Keyboard User Manual

[Home](#) » [RK](#) » RK68 RK855 Wired Mechanical Gaming Keyboard User Manual 

## Contents

- [1 RK68 RK855 Wired Mechanical Gaming Keyboard](#)
- [2 Product Information](#)
- [3 Windows Mode Functions](#)
- [4 Mac Mode Functions](#)
- [5 Backlight Functions](#)
- [6 Three-mode \(Bluetooth/2.4G/wired\) switching/pairing method](#)
- [7 Product Usage Instructions](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

# RK

## RK68 RK855 Wired Mechanical Gaming Keyboard



## Product Information

The 837/855(RKG68.RK68) 3Mode RGB Maunal is a keyboard that comes with standard 68 keys and various function control keys. It supports both wired and wireless modes via 2.4G and Bluetooth connectivity. The keyboard has a backlight feature that allows users to change the brightness, speed, and color of the backlight.

























## Key Functions

- Standard 68 keys
- WIN lock key
- FN combination function control keys
- Wired supports full keys without conflict
- 2.4G/Bluetooth supports six keys without conflict
- **Reset:** Fn+ Space Long Press 3 Secs Fn+Win :Off On Win Fucntion
- indows/IOS switch Fn+A Switch to windows Fn+ s Switch to M ac
- Midea Function

## Reset

To reset the keyboard, press and hold the Fn key along with the Space key for 3 seconds. This will switch between Windows and IOS mode.

## Windows Mode Functions

 +  <b>F1</b>	 +  <b>F7</b>
 +  <b>F2</b>	 +  <b>F8</b>
 +  <b>F3</b>	 +  <b>F9</b>
 +  <b>F4</b>	 +  <b>F10</b>
 +  <b>F5</b>	 +  <b>F11</b>
 +  <b>F6</b>	 +  <b>F12</b>

- **Fn+F1:** Computer
- **Fn+F2:** Browser
- **Fn+F3:** Mailbox
- **Fn+F4:** Calculator
- **Fn+F5:** Player
- **Fn+F6:** Stop
- **Fn+F7:** Previous song
- **Fn+F8:** Play/Pause







- **Fn+F9:** Next song
- **Fn+F10:** Mute
- **Fn+F11:** Volume-
- **Fn+F12:** Volume+

## Mac Mode Functions

Fn + F1	Fn + F7	Last song
Fn + F2	Fn + F8	Play / pause
Fn + F3	Fn + F9	Next song
Fn + F4	Fn + F10	Mute
Fn + F5	Fn + F11	Volume-
Fn + F6	Fn + F12	Volume+

- **Fn+F1:** Next song
- **Fn+F2:** Browser
- **Fn+F3:** Mailbox
- **Fn+F4:** Calculator
- **Fn+F5:** Player
- **Fn+F6:** Stop
- **Fn+F7:** Previous song
- **Fn+F8:** Play/Pause
- **Fn+F9:** Next song
- **Fn+F10:** Mute
- **Fn+F11:** Volume-
- **Fn+F12:** Volume+

## Backlight Functions

Fn +  <b>PrtSc</b>	Fn +  <b>Home</b>
Fn +  <b>Insert</b>	Fn +  <b>End</b>
Fn +  <b>Pause</b>	Fn +  <b>ScrLk</b>

- **Fn+:** Backlight brightness/speed setting
- **FN+, :** Multiple backlight mode switching
- **Fn+. :** Backlight monochrome color switching
- **Fn+:** Backlight brightness increase
- **Fn+:** Backlight brightness decrease
- **Fn+< :** Dynamic change speed is reduced
- **Fn+> :** Increase in dynamic conversion speed

### Three-mode (Bluetooth/2.4G/wired) switching/pairing method

#### Wired Mode:

To use the keyboard in wired mode, connect the USB to the device and switch the power switch to OFF.

#### 2.4G Mode:

To use the keyboard in 2.4G mode, switch 1 to ON and switch 2 to G. To pair the keyboard, press and hold Fn+P until the P key flashes. Insert the receiver, and the P key will stop flashing, indicating successful code pairing. (Note: The receiver has already been paired before leaving the factory, so this step is not necessary unless 2.4G can't connect).



#### Bluetooth Mode:

To use the keyboard in Bluetooth mode, switch 1 to ON and switch 2 to B.



### Product Usage Instructions

1. Connect the keyboard to the device via USB or Bluetooth/2.4G connectivity.
2. Switch to the desired mode using the switches on the back of the keyboard.
3. Use the various function control keys to perform actions such as controlling volume, media playback, and launching applications.


4. Use the backlight function keys to change the brightness, speed, and color of the backlight.
5. Reset the keyboard by pressing and holding the Fn key along with the Space key for 3 seconds.

**Key function:** It is mainly composed of standard 68keys, WIN lock key, and FN combination function control keys. Wired supports full keys without conflict, 2.4G/Bluetooth supports six keys without conflict

### Bluetooth pairing method:

1. Switch 1 to the ON state, switch 2 to the B state,
2. FN+Q/W/E. Long press for any group of pairing codes, such as Fn+Q, at this time, the Q button keeps flashing, indicating that it has entered the pairing state
3. Turn on the computer/mobile Bluetooth, search for an d connect to the device, search for the displayed name: BT3.0Keyboard (connect to the PC terminal Windows 7 or lower system), BT5.0Keyboard\_Por (connect to the Windows 8 or higher system version, mobile devices, etc.)
4. Complete the connection And so on: Repeat the above steps, Q/W/E/ can store 3 sets of Bluetooth devices, short press Fn+Q/W/E when using switching, you can switch between different Bluetooth devices (Reminder: Use Switch Before, please pair 3 sets of Bluetooth)

### Documents / Resources

	<p><a href="#">RK RK68 RK855 Wired Mechanical Gaming Keyboard</a> [pdf] User Manual RK68 RK855 Wired Mechanical Gaming Keyboard, RK68, RK855 Wired Mechanical Gaming Keyboard, Mechanical Gaming Keyboard, Gaming Keyboard, Keyboard</p>
---	--