

ADAM AAOYG481 Projector User Manual

Home » aao » ADAM AAOYG481 Projector User Manual



Contents

- 1 ADAM AAOYG481 Projector
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Safety Notice**
- **5 Interface Introduction**
- **6 Remote Control**
- Introduction
- 7 Multimedia Connection
- 8 Search Page
- 9 Parameters
- **10 Warranty Conditions**
- 11 Documents / Resources
 - 11.1 References
- **12 Related Posts**



ADAM AAOYG481 Projector



Product Information

Specifications

• Imaging Technology: TFT LCD

• Resolution: 1920×1080

• Maximum Compatible Resolution: 1920×1080

• Light: LED

Focus Mode: Electronic focusProjection Distance: 1.5-5.9m

• Screen Size: 49-200 inches (124-508cm)

• Aspect Ratio: 16:9 and 4:3

• **Power Input:** 100-240V, 50/60Hz

Input: USB ×1, HDMI ×1Output: 3.5mm audio jack

• Speaker: 4Ω 3W ×2

• Unit Size: 162×150×228mm

Net Weight: 1.78kgThrow Ratio: 1.36:1

Product Usage Instructions

Safety Notice

Please read the safety instructions in the user manual carefully before using the product.

Interface Introduction

The projector has the following interfaces:

- USB input port
- Power input
- · HDMI input port
- 3.5mm stereo jack
- IR (infrared) receiver
- · Power button

Remote Control Introduction

The remote control features the following buttons:

- Power button
- Focus buttons (for adjusting image clarity)
- OK button
- · Directional buttons (Left, Right, Up, Down)
- Return button
- Volume buttons (+/-)
- Signal source button
- Mute button
- · Homepage button
- · Menu/shortcut button

Multimedia Connection

The projector can be connected to various devices to enhance its potential. The available connections are:

- USB port: Used to access files (videos, music, etc.) from memory devices or mobile phones.
- **HDMI port:** Used for connecting computers, laptops, gaming consoles, or any device that wants to use the projector as an additional screen.
- Audio ports: Used for connecting audio devices (speakers, headphones) to improve sound quality.

USB Connection

To connect a USB device:

- 1. Connect the USB with the content to the projector's USB port.
- 2. Press the Signal Source button on the remote control.
- 3. Select either movie, music, photo, or text to be shown.

HDMI Connection

To connect a device with an HDMI output:

1. Connect the HDMI interface to the projector's HDMI input port.

2. Choose the HDMI channel on the projector.

Audio Device Connection

To connect an audio device:

Use a 3.5mm audio jack to connect the audio device to the projector's 3.5mm stereo jack.

Menu Setup

To access various settings:

- 1. Open the homepage on the projector.
- 2. Go to Setting.
- 3. From there, you can access settings such as Wi-Fi, Bluetooth, projection image, language, date, applications, system update, and more.

Search Page

On the search page, you can search for specific content or information.

My Apps

On the homepage, you can choose and access various applications such as sports, games, music, etc. You can delete unwanted applications by long-pressing the Menu/shortcut button.

FAQ

· How do I adjust the focus of the image?

Use the focus buttons on the remote control to adjust the image clarity.

What devices can be connected to the projector?

The projector can be connected to devices such as computers, laptops, gaming consoles, memory devices, mobile phones, speakers, and headphones.

How do I update the system?

To update the system, go to the Setting menu and look for the System update option.

Where can I find more information about the device?

In the Setting menu, you can find more information about the device.

Dear customer,

Thank you for purchasing our product. Please read the following instructions carefully before first use and keep this user manual for future reference. Pay particular attention to the safety instructions. If you have any questions or comments about the device, please contact the customer line.


- www.alza.co.uk/kontakt
- +44 (0)203 514 4411
- Importer Alza.cz a.s., Jankovcova 1522/53, Holešovice, 170 00 Praha 7, www.alza.cz

Safety Notice


- Please read the manual carefully before you use the projector for the first time.
- To ensure stable power supply, please use national standard power cable and power cord with grounding.
- Please use the right power cord for the projector, improper power cord may cause damage to the projector.

- Please do not disassemble the machine yourself, otherwise the company will not undertake warranty service.
- Do not look directly at the projector lens while the machine is operational, as it may cause damage to your eyesight.
- To prevent clogging on the projector vents, do not cover the device with cloth, carpet, or other materials.
- This projector is not waterproof, please keep it away from rain, moisture, and other items containing liquid, such as vases, cups, etc.
- To prevent electric shock, please keep t he projector away from rain, water, or moisture.
- Cut off the power supply if the projector is not used for a long time.
- Use the original foam or other unit-shock material to protect projector if you need to transport it.
- If you find that your projector is having some issues, please do not attempt to repair it yourself. Contact the Alza support team using means provided at the beginning of this user manual.
- To extend the projector life span and protect your eyesight, we suggest you to have a break after 3-4 hours of using the device.

Interface Introduction



Remote Control Introduction



Notes:


- To avoid power shortage, please do not mix up the old batteries and the new.
- To avoid battery leakage corrosion, please take the batteries out if the remote control is not used for a long time.
- When using the remote control, please align the remote control signal transmitter to the projector's infrared signal reception point.

Focus adjustment:

Using the focus buttons on the remote control, you can adjust the image clarity.

Multimedia Connection


• There are various devices that can be connected to the projector to enhance its potential or use it to its fullest.



• Generally, USB port (1) is used to access files to be projected on the device, such as videos and music, both from memory devices or mobile phones and so on. HDMI port (2) is used for connecting computers, laptops, or gaming consoles; generally, any device that wishes to use the projector as an additional screen. Finally, audio ports (3) are used for connecting audio devices, such as speakers or headphones, to make sound quality better or non-intrusive.

USB Connection


Connect the USB with the content to the project USB port, press the Signal Source button on the remote control. There, you can select either movie, music, photo, or text to be shown.






• HDMI Connection

HDMI interface can be connected to computers and other devices with HDMI output interface. After connecting to such device, choose the HDMI channel.



• Audio Device Connection

Using 3.5mm audio jack you can connect audio devices to the projector.



Search Page

On this page, you can search for whatever you're interested in.



Menu Setup

- Open the homepage and go to Setting. There, you can access a variety of settings, such as Wi-Fi Setting, Bluetooth Setting, Projection image setting, Language setting, Date setting,
- Application setting, System update, Other settings and more information about the device.





My Apps

On the homepage, you can choose applications, such as sports, games, music, and so on. Delete applications you are not interested in by a longer pressing of the Menu/shortcut button.






Parameters

- Imaging Technology TFT LCD
- Resolution 1920×1080
- Maximum Compatible Resolution 1920×1080
- Light LED
- Focus Mode Electronic focus
- Projection Distance 1.5-5.9m
- Screen Size 49-200 inches (124-508cm)
- · Aspect Ratio 16:9 and 4:3
- Power Input 100-240V, 50/60Hz
- Input USB ×1, HDMI ×1
- · Output 3.5mm audio jack
- Speaker 4Ω 3W ×2
- Unit Size 162×150×228mm
- Net Weight 1.78kg
- Throw Ratio 1.36:1

Projector Distance & Size



Note: Doe to optics error of 3%, the data above is for reference only, please use an actual measurement when installing the device.

Warranty Conditions

• A new product purchased in the Alza.cz sales network is guaranteed for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the date of purchase.

The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:

- Using the product for any purpose other than that for which the product is intended or failing to follow the instructions for maintenance, operation, and service of the product.
- Damage to the product by a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (e.g., during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid intrusion, object intrusion, mains overvoltage, electrostatic discharge voltage (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes such as used power supplies,

etc.

• If anyone has made modifications, modifications, alterations to the design or adaptation to change or extend the functions of the product compared to the purchased design or use of non-original components.

EU Declaration of Conformity

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and Directive 2011/65/EU amended (EU) 2015/863.



WEEE

This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19 / EU). Instead, it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.



Documents / Resources

aao ADAM AAOYG481 Projector [pdf] User Manual ADAM AAOYG481 Projector, ADAM AAOYG481, Projector

References

- Range Alza.sk rýchly a pohodlný nákup odkiaľkoľvek | alza.sk
- O Alza | Alza.co.uk
- <u>§ alza.de</u>
- User Manual

Manuals+, Privacy Policy