




## ABUS CFF3100 HomeTec Pro Bluetooth Remote Control Instruction Manual

[Home](#) » [ABUS](#) » ABUS CFF3100 HomeTec Pro Bluetooth Remote Control Instruction Manual 

ABUS CFF3100 HomeTec Pro Bluetooth Remote Control



**Thank you for choosing this ABUS product!**

Please read this guide carefully before use. Keep these instructions and provide all users with instruction on how to use it.

To set up your HomeTec Pro Bluetooth® door lock drive for the first time, you will need a Bluetooth®-enabled smartphone (Bluetooth® 4.0 LE or higher), a currently supported iOS or Android software version and the free ABUS HomeTec Pro app for iOS or Android. The drive can be operated with either a smartphone (Bluetooth® and the ABUS HomeTec Pro app) or with the other HomeTec Pro components. The remote control serves as an alternative to using a smartphone. A CFF3100 remote control can operate a maximum of two door lock drives CFA3100. The contents of this installation and operating manual reflect the current status at the time of printing. The printed manual may be outdated at the time of the product's entry into service due to updates and further developments. We therefore ask you to visit our website and enter „CFF3100“ into the search bar. You'll always find the current and complete version of the installation and operating instructions on the product page under the „Downloads“ column.

## Contents

### 1 OVERVIEW

### 2 PARTS

### 3 HomeTec Pro App

### 4 Battery replacement

### 5 Technical data

### 6 Legal information

#### 6.1 Battery instructions

#### 6.2 EU Declaration of Conformity

#### 6.3 UK Declaration of Conformity

#### 6.4 Disposal

#### 6.5 Warranty


#### 6.6 Licence text

### 7 Documents / Resources


#### 7.1 References

### 8 Related Posts

## OVERVIEW




## PARTS








## HomeTec Pro App




- Download the ABUS HomeTec Pro app and enable Bluetooth® on your smartphone.
- Start the app and follow the instructions in the app.
- Pay attention to the assignment of the different Keycards to the products, and always scan the correct Keycard.
- To program the remote control, start by pressing the button „Add HomeTec Pro / component“.
- **It is imperative to keep the ABUS Keycard(s) in a secure place even after completing the setup!** You need the Keycard for software updates, if you lose your smartphone, and for proof of ownership for matters related to warranty claims and repair. Do not give the Keycard to third parties.

To guarantee proper function, we expressly recommend performing updates in the app and software/firmware updates for HomeTec Pro components in a timely manner. The app will provide information on this. You can also perform the respective update in the component's settings.


## Battery replacement




**click!**




**Lift the lid, do  
not twist!**





**Do not touch  
sensitive com-  
ponents!**



## Technical data

Dimensions	63 x 30 x 11 mm
Weight (without battery)	18 grams
Battery type	1 * CR2032 3 V Lithium-polymer
Operating temperature range	0°( to +40°(
Radio frequency	2,402 GHz – 2,480 GHz
Max. radiated trans- mission power	< 10dBm eirp
Encryption	AES-128 bit

## Legal information

## Battery instructions

- This product contains a lithium button cell CR2032.
- Keep batteries out of the reach of children. Children may put batteries in their mouths and swallow them. This can cause serious harm to their health. Seek immediate medical attention in this event!
- Batteries must be inserted with the correct polarity (+ and -).
- Empty batteries must be removed or replaced immediately.
- The battery terminals must not be short-circuited.
- Risk of burns from contact with leaking or damaged batteries! In these cases, use suitable protective gloves and clean the battery compartment with a dry cloth.
- Batteries must not be dismantled, punctured, damaged, short circuited, heated, charged or thrown into an open fire (risk of explosion!).
- Do not use or store the product in areas where the temperature could reach below 0°C or above +40°C. Do not expose the product to direct sunlight for long periods of time.

## EU Declaration of Conformity

Hereby, ABUS August Bremicker Söhne KG declares that the radio equipment type HomeTec Pro is in compliance with Directives 2014/53/EU and 2011/65/ EU. The full text of the EU declaration of conformity is available at the following internet address: [docs.abus.com](https://docs.abus.com)

## UK Declaration of Conformity

Hereby, ABUS August Bremicker Söhne KG declares that the radio equipment type HomeTec Pro is in compliance with the Radio Equipment Regulations 2017 and the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012. The full text of the UK declaration of conformity is available at the following internet address: [docs.abus.com](https://docs.abus.com)

## Disposal

It is your responsibility to delete all stored personal data prior to disposal of the product. This product contains valuable raw materials. At the end of its service life, dispose of the product in accordance with the applicable legal requirements. Electrical appliances, rechargeable batteries and batteries must not be disposed of with household waste. Disposal must be carried out in accordance with Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), or Directive 2006/66/EC on batteries and accumulators and waste batteries and accumulators. Batteries must be removed from electrical appliances and disposed of separately before disposal. Dispose of the packaging according to type. Separate the cardboard, foil and plastic elements for recycling. Please contact the local authority responsible for disposal if you have any queries. You can obtain information on collection points for your old appliances, for example, from the local municipal or city administration, the local waste disposal companies, or your specialist

## Warranty

ABUS products are designed, manufactured and tested in accordance with applicable regulations with great care. The warranty exclusively covers faults that are caused by material or manufacturing defects. If a material or manufacturing defect can be proven, the product will be repaired or replaced at the discretion of the warrantor. In such cases, the warranty ends with the termination of the original warranty period. Any further claims are expressly excluded. ABUS assumes no liability for defects or damage that has been caused by external influences (e.g. transport, external forces), improper use, normal wear and tear or non-compliance with this operating and installation instructions document. If a warranty claim is asserted, the product must be returned with the original receipt with date of purchase and a brief written description of the fault.

## Licence text

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ABUS August BremickerSöhne KG is under license. Other trademarks and brand names are those of their respective owners.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries and regions. App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

Subject to technical alterations. No liability for mistakes and printing errors.

[www.abus.com](http://www.abus.com)




WEEE-Reg.-No DE79663011




Security Tech Germany

## Documents / Resources

	<p><b><a href="#">ABUS CFF3100 HomeTec Pro Bluetooth Remote Control</a></b> [pdf] Instruction Manual CFF3100, HomeTec Pro Bluetooth Remote Control, CFF3100 HomeTec Pro Bluetooth Remote Control, Bluetooth Remote Control, Remote Control</p>
---	--

## References

-  [Declarations of conformity - Service - ABUS](#)
-  [ABUS - August Bremicker Söhne KG](#)

Manuals: