

ACASIS EC7252 2.5 Inch Dual Disk Hard Disk Array Box



ACASIS EC7252 2.5 Inch Dual Disk Hard Disk Array Box Instruction Manual

[Home](#) » [ACASIS](#) » ACASIS EC7252 2.5 Inch Dual Disk Hard Disk Array Box Instruction Manual 

Contents

- [1 ACASIS EC7252 2.5 Inch Dual Disk Hard Disk Array Box](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Package Contents](#)
- [5 RAID settings](#)
- [6 Connect to computer \(USB3.0, USB2.0\)](#)
- [7 Product Warranty](#)
- [8 Install Easily](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

ACASIS

ACASIS EC7252 2.5 Inch Dual Disk Hard Disk Array Box



Product Information

Specifications:

- Product: 2.5-inch dual Disk Hard Disk Array Box
- Package Contents:
 - 2.5-inch dual-bay hard disk array x1
 - 5V/4A power cord x1
 - USB data cable x1
 - Installation screw package x1
 - User manual (including warranty card) x1
 - Install screwdriver x1
- RAID Modes: JBOD mode (factory default), 4 modes available
- Data Backup: Required before setting up RAID modes
- Maximum Single Disk Capacity: 6TB

Product Usage Instructions

RAID Settings:

- EC-7252 has 4 RAID modes.
- Factory default mode is JBOD.
- Use the dial on the device to adjust RAID mode.
- All data will be deleted when setting RAID modes, so backup data first!

Connecting to Computer:

USB 3.0 Interface:

1. Use USB 3.0 cable to connect to PC.
2. Eject hard disk safely before disconnecting.

USB 2.0 Interface:

1. Use DC cable for power supply.
2. Use USB 3.0 cable to connect to PC.
3. Eject hard disk safely before disconnecting.

Formatting and Initialization:

- New hard disk must be initialized and formatted.
- After setting RAID mode, hard disk must be formatted.
- If disassembled, reassign access path to identify hard disk.
- Resetting RAID mode will clear data.

Product Warranty:

This product is covered by a warranty period of 12 months. ACASIS does not warrant its products from defects or damages arising from misuse, abuse, or normal wear.

Limitation of Liability:

In no event shall ACASIS INC.CO.,Ltd be liable for any damages (whether direct or indirect, special, incidental, consequential, or otherwise), loss of data, arising out of, or related to the use of this product exceeding the actual price paid for the product.

About After-Sales Regulations:

1. This product is covered by a warranty period of 12 months from the date of purchase.
2. The company is not responsible for the data loss of the hard disk.
3. Important data should be backed up at any time to prevent data loss.
4. There will be differences between the pictures in this manual and the actual product.
5. The appearance and specifications of the product will be upgraded and improved accordingly due to quality improvement and technological progress.

Installation:

1. Remove the screws.

2. Take out the hard disk tray.
3. Install hard disks.
4. Install the tray & screw on the screws.

Foreword

Dear user, thank you for purchasing Acasis product. In order for you to have a better understanding of the product, please read this manual carefully before use. I wish you a pleasant experience!

Package Contents


- 2.5-inch dual-bay hard disk array* 1
- 5V/4A power cord* 1
- USB data cable*1
- Installation screw package*1
- User manual (including warranty card)*1
- Install screwdriver*1

RAID settings

***After setting up RAID, the hard disk will be formatted, please backup data in advance**

1. EC-7252 has 4 RAID modes
2. The factory default is JBOD mode
3. You can use the dial on the device to adjust the RAID mode

- **RAIDO:** The identified capacity is twice the capacity of the small hard drive in the two hard drives.




Setting: Both dial codes are dialed to the digital position

Example: 1000GB+750GB=1500GB

Note: If any hard disk fails, all data will be lost

- **RAIDI:** only recognize one hard disk to store data, and back up to another hard disk at the same time.




Setting: Dial number 1 to a number, dial number 2 to "ON"

Example: 1000GB+750GB=750GB


Note: If any hard disk fails, the data will not be lost

- **JBOD:** Recognized as two hard disks. (factory default setting mode)



Setting: Both dials are dialed to “ON” and the computer recognizes them as two independent hard drives

- **SPAN:** recognized as a hard disk, the capacity is the sum of two hard disks



Setting: Dial 1 to “ON”, Dial 2 to a number

Example: 1000GB+750GB=1750GB

NOTE: The computer will recognize them as one large hard drive

All data will be deleted when setting RAID modes, please backup your data first!

- When connecting the enclosure to USB 2.0 interface of the computer, please use the DC cable in the package for power supply.
- A single disk supports a maximum of 61B.
- When using a brand new hard disk, it must be initialized and formatted to be recognizable.
- After setting up RAID mode, the hard disk must be formatted to be recognizable.
- The disassembled hard disk may cause path conflict, and you need to reassign the access path to identify it.
- Resetting RAID mode will cause the data to be cleared.

Connect to computer (USB3.0, USB2.0)

Connect to USB3.0 interface

1. Use the USB3.0 cable in the package to connect to the USB interface of the PC
2. When disconnecting, first eject the hard disk safely and then unplug the cable.

Connect to USB2.0 interface

1. Use the DC cable in the package to connect to the PC
2. Use the USB3.0 cable in the package to connect to the USB interface of the PC
3. When disconnecting, first eject the hard disk safely and then unplug the cable.

Product Warranty

This product is covered by a warranty period of 12 months.

ACASIS does not warrant its products from defects or damages arising from misuse, abuse, or normal wear.

Limitation of Liability

In no event shall ACASIS INC.CO.,Ltd be liable for any damages (whether direct or indirect, special, incidental, consequential, or otherwise),loss of data, arising out of, or related to the use of this product exceeding the actual price paid for the product. About after-sales regulations

1. This product is covered by a warranty period of 12 months from the date of purchase
2. The company is not responsible for the data loss of the hard disk
3. Important data should be backed up at any time to prevent data loss
4. There will be differences between the pictures in this manual and the actual product
5. The appearance and specifications of the product will be upgraded and improved accordingly due to quality improvement and technological progress.

Install Easily



Installation

1. Remove the screws
2. 2 Take out the hard disk tray
3. Install hard disks
4. Install the tray&Screw on the screws

FAQ


Q: Unrecognizable?

A: The hard disk connected to the device will be a new hard disk that has not been formatted or the drive character has not been assigned. My computer -> management -> disk management, run formatting.

Q: The LED of the device does not light up?

A: Make sure the USB cable is connected properly. If there is an insufficient power supply when connecting to the USB2.0 interface, use the DC cable in the package to connect.

Documents / Resources

	ACASIS EC7252 2.5 Inch Dual Disk Hard Disk Array Box [pdf] Instruction Manual EC7252 2.5 Inch Dual Disk Hard Disk Array Box, EC7252, 2.5 Inch Dual Disk Hard Disk Array Box, Dual Disk Hard Disk Array Box, Disk Hard Disk Array Box, Hard Disk Array Box, Disk Array Box, Array Box
---	---

References

- [S inc.co - inc Resources and Information.](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.