



accessstyle Grape 20WC Charging Adapter User Manual

[Home](#) » [accessstyle](#) » accessstyle Grape 20WC Charging Adapter User Manual 



Thank you for purchasing the Grape 20WC charger. Please read the instructions carefully before use.

Contents

- 1 Specifications
- 2 The set includes
- 3 Charger’s appearance and features
- 4 Key features
- 5 How to use the charger
- 6 Safety notices
- 7 Accesstyle warranty terms and conditions
- 8 Warranty certificate
- 9 Documents / Resources
- 10 Related Posts

Specifications

Input ports	100-240V / 50-60Hz
Output ports	USB-C
Output voltage / current USB-C	5V/3A, 9V/2.22A, 12V/1.67A (20W)
Max power, USB-C	20W
Compatibility	QC 3.0, PD 20W
Dimensions w/o packaging	35*29*68 mm
Net weight	38 g

The set includes

- 1. Charger – 1 pc.
- 2. Instructions – 1 pc.

Charger’s appearance and features



Key features

The charger is equipped with USB-C ports and provides up to 20W charging power. The ports are available for simultaneous operation. The Quick-charge 3.0 compatibility allows users to charge compatible cell phones and other devices faster than conventional wall chargers. Charging speed is limited by the maximum power of the port used, as well as by the specifications of the phone, cable, and the device temperature.

The charger is compatible with the Power Delivery protocol and is capable of providing up to 20W USB-C charging power. This allows it to charge handsets and also supply power to equipment compatible with this standard.

How to use the charger

To charge your mobile device, connect the charging port of your phone to any of the charger's ports with a cable. It is advisable to use the USB-C port as the most powerful port. Next, plug the charger into an electrical outlet.

Note: The charging cable is not included and must be purchased separately. It is advisable to use the cable supplied with the to-be-charged device.

Safety notices

Never disassemble, open, bend, puncture, subject the device to mechanical stress or immerse in liquid. Keep the device and its contacts clean.

Do not swallow!

Keep out of the reach of children!

When used outside the operating temperature range (below -10°C and above $+45^{\circ}\text{C}$), the device will limit the power or turn off automatically.

Do not disassemble the device, do not short circuit. This device must be disposed of separately. Transportation of the products can be carried out in the manufacturer's containers by all means of transport at any distance.

Accessstyle warranty terms and conditions

1. The warranty period of this Product is 1 (one) year starting from the time of the original purchase.
2. The product's lifetime is 2 (two) years and shall commence at the date of purchase, or, failing that, production date;
3. This warranty shall not apply to:
 - 3.1. Cables, adapters, variety of media (discs, memory cards with software), cases, extension cables, clips, variety of holders, package and documents.
 - 3.2. Normal wear and tear or the product's outer surface damages.
 - 3.3. Defects caused by moisture, dampness, extreme temperature, microwave energy, pressure, hit, influence of animals and insects, liquids, food, dust and chemicals entering the product.
 - 3.4. Product, repaired or modified by persons, except those names in paragraph 5.
 - 3.5. Product, misused or used in violation of the user manual.
 - 3.6. Defects caused by use of incompatible equipment or accessories.
4. Warranty service shall be performed by dully authorized bodies: authorized service centers listed on Support webpage: <http://www.ac-cesstyle.ru> and available on 8-800-250-07-17. During the warranty period any production defects shall be repaired free of charge upon presenting the filled valid warranty certificate and/ or documents indicating the proof of purchase and the date of purchase (cash receipt). The documents shall contain model name of the product, date of purchase, trade organization details. An authorized body shall be entitled to refuse warranty service in case of absence of the required documents
5. Warranty period shall be extended to the service period. Replacing of parts, components or the whole package

shall not result in a new warranty period for the product or for the replaced parts.

6. Under no circumstances shall the Producer, Importer and organizations authorized by the Importer be liable for any direct, indirect, incidental, special or consequential damage or including but not limited to, any loss of profit, loss/ loss of use of information or data; information or data restoration costs, loss arising out of use or inability to use Accesstyle products resulted in interruption of a commercial, production or other activity.

Warranty certificate

Product name:.....

Serial number:.....

Date of purchase:.....

Signature of the sales person:.....


Trade organization name and address:.....

The quality of product has been checked in my presence, I have no claims. I have obtained the full and complete product. I hereby declare that I have read and agree with the warranty terms and conditions.

Customer Signature.....



Documents / Resources

	<p>accesstyle Grape 20WC Charging Adapter [pdf] User Manual Grape 20WC, Grape 20WC Charging Adapter, Charging Adapter</p>
---	---