

# **ACDC DYNAMICS SPF26V-100 Lithium Battery User Manual**

Home » ACDC DYNAMICS » ACDC DYNAMICS SPF26V-100 Lithium Battery User Manual

# ACDC DYNAMICS SPF26V-100 Lithium Battery



#### **Contents**

- 1 THANK YOU
- **2 BASIC INTRODUCTION**
- **3 DANGER WARNING**
- **4 TRANSPORTATION AND STORAGE**
- **5 TYPICAL FAULTS AND TROUBLESHOOTING**
- **6 PRECAUTIONS FOR HANDLING ABNORMAL**

**PROBLEMS** 

- **7 MAINTENANCE AND AFTER SALES**
- **8 OTHER MATTERS**
- 9 AFTER-SALE SERVICE
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts

# **THANK YOU**

Thank you very much for choosing ACDC lithium ion battery! In order to help you use, store and maintain the lithium battery of our

company, please read and understand this user manual carefully before use.

- Red (+)
- Black (-)

## **BASIC INTRODUCTION**

# **BATTERY SPECIFICATION**

Code	SPF26V-100
Nominal voltage V	25.6V
Nominal capacity Ah	100Ah
Charging mode	CC/CV (Lithium ion battery specialized charger)
Charging voltage V	28.8V
Maximum charging curren t A	100A
Maximum discharge curren t A	100A
Size (mm)	532*207*215mm
Recommended discharge cut off voltage	22.4V

## **Environmental conditions**

- 1. Charging temperature range 0°C~45°C
- 2. Discharge temperature range -20°C~50°C
- 3. Storage temperature range  $-10^{\circ}\text{C}\sim45^{\circ}\text{C}$

#### 4. Relative humidity 5%-90%

#### **CHARGE**

- 1. The battery pack must be charged with a specialized charger for lithium battery. When charging the battery, make sure that the power supply voltage is consistent with the input voltage of the charger, and the output voltage of the charger is consistent with the battery's charging voltage. Unqualified chargers will lead to battery failure or short life.
- 2. When charging the battery, connect the charger output end to the battery charging port first, and then insert the charger into the socket. Do not connect and disconnect continuously.
- 3. The charging position shall be well ventilated. Do not charge in high temperature environment, and keep away from inflammable and explosive gases or objects. The charger and battery shall be placed on a stable, level surface
- 4. It is normal that the surface of the battery box is slightly heated during charging. If it is found that the surface temperature of the battery box is too high, the power must be cut off immediately and the battery pack sent to the designated after sales service station for assessment.
- 5. Once fully charged, disconnect the charger from the battery.
- 6. When the battery leaves the factory, the SOC is between 40% 60%, battery must be fully charged before use.
- 7. It is strictly forbidden to directly contact any positive or negative terminals, or short-circuit any positive and negative terminals, which could result in injury or damage to equipment
- 8. The maximum charging time shall not be more than 12 hours (the specific charging time depends on the use of the battery), and the battery shall not be charged continuously.

#### **OPERATION**

- 1. The battery should only be used for the intended purpose, not for other purposes.
- 2. The battery shall be firmly installed on the electric vehicle or other electric equipment, so as to avoid damage due to movement during the operation of the equipment.
- 3. Do not expose the battery to moisture (e.g. rain) to prevent moisture from penetrating into the battery and affecting the service life of the battery pack.
- 4. Do not immerse the battery in water.
- 5. The performance of the battery will be affected by the ambient temperature. Operation at temperatures outside of the rated operating temperature will decrease battery pack performance
- 6. The battery shall be placed in an area free from direct sunlight or other radiation sources, and the minimum distance from any heat source (fire source, heating, equipment, etc.) shall not be less than 2m.
- 7. The built-in battery management system could be damaged by static electricity. Please make sure to protect the battery pack against static discharge.
- 8. If abnormal phenomena such as a peculiar smell occurs during operation, discontinue use and return to the after sales outlet immediately for assessment.
- 9. This device should only be used or installed by qualified personnel. Keep out of reach of children.

#### SERIES OR PARALLEL CONNECTION

1. The battery supports a maximum of four batteries connected in series or four batteries connected in parallel.

When multiple battery packs are used in parallel, ensure that the voltage difference between the packs before parallel connection is as small as possible.

- 2. When multiple battery packs are used in parallel, the total charging surge current of the charger may be applied to a single battery pack. It should be ensured that the total charging surge current of the charger does not exceed the maximum charging surge current of a single battery.
- 3. When connecting battery with cables, make sure not to reverse the polarity of the connections. If it is indeed connected incorrectly, the BMS may be damaged. It needs to be retested and qualified before use.

# **DANGER WARNING**

- 1. Do not disassemble the battery!
- 2. Do not short circuit the battery!
- 3. Do not use battery in water or in liquid!

## TRANSPORTATION AND STORAGE

## **Transportation:**

- 1. Battery transportation temperature: 20 ~ 30°C.
- 2. Batteries shall be packed in boxes for transportation, and vehicles such as cars, trains and cabins can be used.
- 3. During transportation, the battery shall not be subject to severe vibration, impact, exposure to moisture, inversion and heavy pressures;
- 4. The battery shall be handled with care during loading and unloading. Throwing, rolling, compressing and dropping of battery are strictly prohibited.

#### Storage

- 1. When the battery is not used for a long time (more than 3 months), please remove it from the device, charge the battery to the semi saturated state, and then store it in a cool and dry room, and charge every three months.
- 2. It is strictly prohibited to store the battery at a low state of charge
- 3. The battery shall be stored in a dry and well ventilated place to avoid contact with corrosive substances, keep away from fire and heat sources, and disconnect the charger from the battery

## TYPICAL FAULTS AND TROUBLESHOOTING

Fault Pheno menon	Reason	Processing method
Unable to ch arge normall y	Charger not plugged in Charger faulty The terminal is dirty or the terminal is not properly faste ned BMS is in protection mode Battery circuit fault	Check charger connector Replace charger Clean the terminals and tighten the sc rews Disconnect the battery for 30 seconds and reconnect Please contact the nearest dealer for repair.
Abnormal dis charge	Polarity error The battery SOC is too low Battery circuit fault	Check polarity Fully charge the battery before use Please contact the nearest dealer for repair
Abnormal dis charge stop	Operation temperature too high, trigger over temperature protection Excessive discharge current, triggers over current prote ction External short circuit of battery, triggering short circuit p rotection	Disconnect the load and allow the bat tery to rest for half an hour at room te mperature Reduce discharge current Turn off the device, disconnect the bat tery, remove the short circuit and then reconnect

## PRECAUTIONS FOR HANDLING ABNORMAL PROBLEMS

- 1. This product should be repaired by professional personnel. If you open the battery shell by yourself, the warranty service will be terminated.
- 2. If the battery is seriously impacted, compressed, dropped or heated, it must not be used and must be sent to the product agent or after-sales service office of the company in time for maintenance.

## **MAINTENANCE AND AFTER SALES**

- 1. According to the relevant laws and regulations of the state, the company carries out warranty for the products normally sold.
- 2. When your battery needs to be repaired, please bring the purchase battery invoice and this warranty card to our company or the dealer's designated after-sales service station for repair.
- 3. Failure caused by unauthorized disassembly and assembly, unauthorized maintenance and use not in accordance with the instructions is not covered by the warranty.
- 4. Faults and losses caused by charging, use, maintenance, storage or transport not in accordance with the requirements of this manual are not within the scope of warranty and liability.

# **OTHER MATTERS**

- 1. To ensure safe operation and proper function, please read this manual in detail before using the battery.
- 2. Please keep this manual for future reference
- 3. The company will not bear any legal liability for direct and indirect losses caused by improper use.
- 4. If there is any discrepancy between the supplied product and the instruction manual due to the continuous development of the product, the supplied product will be referred to
- 5. The company reserves the right to interpret the specification.

6. The company reserves the right to modify this manual without prior notice.

#### **AFTER-SALE SERVICE**

TEL: +2710 202 3300 WEB: https://acdc.co.za/

Physical address: 26 Nguni Drive, Longmeadow Estate West, Edenvale Gauteng South Africa

National Sales Centre - 010 202 3400 | Technical - 010 202 3500 www.acdc.co.za THINK ELECTRICAL

BRANCHES – Johannesburg: 010 202 3300 | Germiston: 011 418 9600 | Cape Town: 021 492 2000 | Riverhorse: 031 492 4800 | Pinetown: 031 700 4215



#### **Documents / Resources**



ACDC DYNAMICS SPF26V-100 Lithium Battery [pdf] User Manual SPF26V-100, SPF26V-100 Lithium Battery, Lithium Battery, Battery

# References

- ACDC Dynamics Online
- ACDC Dynamics Online
- User Manual

Manuals+, Privacy Policy