




## ACME SP109 Dynamic Bluetooth Speaker User Manual

[Home](#) » [acme](#) » ACME SP109 Dynamic Bluetooth Speaker User Manual 

# acme<sup>®</sup>

SP109 Dynamic Bluetooth Speaker  
User Manual





## Contents

- [1 Overview](#)
- [2 Important Safety Precautions](#)
- [3 Functions Description](#)
- [4 Warranty card](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

## Overview

1. Function button / Power Switch
2. Audio In
3. Charging socket

<b>&lt;  V-</b>	Previous track/Volume -: Press this button to select tracks or press and hold it to reduce the volume .
<b>V+ &gt; </b>	Next track/Volume +: Press this button to select tracks or press and hold it to increase the volume.
<b>&gt;   &lt;</b>	Pause/Play/Pick or end the call: Press this button to pause, resume normal operation, or pick up/end calls in the Bluetooth playback mode.

## Important Safety Precautions

- For the best results, place your speaker on a solid, flat surface when in use.
- Do not touch the metallic parts of your connector cables.

- In order to avoid electric shocks and other such accidents, do not dismantle or take apart the speaker.
- Do not expose your speaker to excessive amounts of heat or cold. Keep it in a well-ventilated area to prevent it from overheating.
- Turn off your speaker when you are not using it.
- Do not spill liquids or fluids on your speaker.
- When connecting an audio device to your speaker, make sure the volume on the audio device is not set too high, in order to avoid excessive signal input.
- This speaker should not be placed near open flames, such as lit candles.



## Functions Description

**Turning on:** Use the power switch to turn the speaker on. It will beep and the blue indicator will flash simultaneously.

**Bluetooth Connection:** Once switched on, the speaker starts searching for other Bluetooth devices automatically, and at the same time, the blue indicator flashes. If pairing is successful, the blue indicator flashes slowly and a notification sound is also generated by the speaker. If speaker is not paired with any other Bluetooth device within five minutes, the speaker will shut itself down. Turn it on to start the search again. All the paired devices will engage in automatic connection when the speaker is turned on.

**Note:** Please recharge if the device repeatedly shuts down or the connection fails.

**Bluetooth Music Playback:** When connected, the speaker plays music immediately. Press **◀ V-** and **V+ ▶** to select the next or previous tracks. Press and hold **◀ V-**, and **V+ ▶** adjust the volume. While playing the music, press **⏸** pause or resume.

**Call Pick-up:** After it has been successfully connected to the cell phone, the speaker will beep when a  call is received. Press to pick it up, and press  again to end a call.

**AUX Playback:** Use the supplied audio cable to connect the speaker to another music player, such as a computer, by plugging one end into the speaker's audio port and the other end into the music player's audio port. Tracks can be selected only through the music player, but volume can be controlled through both the music player and Bluetooth speaker. You can press pause/play.

**Recharging:** Plug the supplied USB cable into the speaker's USB socket and the other end into the computer's USB port or the USB charger. When fully charged, the red indicator will turn off.

## Waste Electrical and Electronic Equipment (WEEE) Symbol



The use of the WEEE symbol indicates that this product may not be treated as household waste.

By ensuring this product is disposed of correctly, you will help protect contact your local authority, your household waste disposal service provider, or the shop where you purchased the product.

## Warranty card

Product	Product model
Product purchase date	Seller name, address
Failures (date, description, position of the person who accepts the product, first name, last name, and signature)	

### 1. Warranty period

Warranty enters into force starting with the day when the buyer acquires the product from the seller. The warranty period is indicated on the package of the product.

### 2. Warranty conditions

The warranty is valid only by providing an original document of the product acquisition and this warranty sheet, which includes name of the product model, product purchase date, and name and address of the seller.

If it is noticed during the warranty period that the product has faults and these faults were not caused by any of the reasons when the warranty is not applied as indicated in the paragraphs below, the manufacturer undertakes to replace the product.

The warranty is not applied to regular testing, maintenance, repair, or replacement of the parts which are worn out naturally.

The warranty is not applied if damage or failures occurred due to the following reasons:

- Inappropriate installation of the product, inappropriate usage and/or operation of the product without following the manual, technical requirements, and safety standards as provided by the manufacturer, and additionally, inappropriate warehousing, falling from heights as well as hard strikes.
- Corrosion, mud, water, and sand.
- Repair works, modifications, or cleaning, which were performed by a service not authorized by the manufacturer.
- Usage of spare parts, software, or consumptive materials which do not apply to the product.
- Accidents or events or any other reasons which do not depend on the manufacturer, which include lightning, water, fire, magnetic field, and inappropriate ventilation.
- If the product does not meet the standards and specifications of a particular country, in which it was not bought. Any attempt to adjust the product in order to meet technical and safety requirements such as those in other countries withdraws all the rights to the warranty service.

If no failures are detected in the product, all the expenses in relation to the service are covered by the buyer.

**acme**<sup>®</sup>

Model: SP109



Designed in the EU by ACME Europe UAB,  
Raudondvario pl. 131B, LT-47191, Kaunas, Lithuania

Rev. 1.0


Printed in China

**TM.by**  
ONLINE STORE

<https://tm.by>

[www.acme.eu](http://www.acme.eu)

## Documents / Resources



[ACME SP109 Dynamic Bluetooth Speaker](#) [pdf] User Manual

SP109, Dynamic Bluetooth Speaker, SP109 Dynamic Bluetooth Speaker, Bluetooth Speaker, S peaker

## References

-  [ACME Homepage | acme](#)

Manuals+.