



ACT AC6015 USB Smart Card ID Reader Instruction Manual

[Home](#) » [ACT](#) » ACT AC6015 USB Smart Card ID Reader Instruction Manual 

Contents

- [1 ACT AC6015 USB Smart Card ID Reader](#)
- [2 CONNECTION](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)


ACT

ACT AC6015 USB Smart Card ID Reader




CONNECTION

1. Check our website www.act-connectivity.com for the latest AC6015 drivers. Fill out "AC6015" in the search field and press "Enter". Please choose AC6015 and select "Downloads". Download and install the correct driver for your Operating System.
2. Connect the USB Smart Card Reader to a USB port.



3. In order to use the AC6015, you need to use a smart card or an eID card and software which allows you to read from these types of cards. This software will be supplied by your bank, the government of your country, or other certified instances.



You can find safety information at www.act-connectivity.com/safety NL Kijk op www.act-connectivity.com/safety voor de veiligheidsinformatie. For service, manuals, firmware or updates visit www.act-connectivity.com NL Voor service, handleidingen, firmware updates bezoekt u www.act-connectivity.com.

Documents / Resources



[ACT AC6015 USB Smart Card ID Reader](#) [pdf] Instruction Manual

AC6015, USB Smart Card ID Reader, AC6015 USB Smart Card ID Reader, Smart Card ID Reader, ID Reader, Reader

References

- [A Home | ACT](#)
- [A Home | ACT](#)
- [A Safety instructions | ACT](#)
- [Taalkeuze | eID software](#)
- [java.com](#)