



Actiontec MoCA 2.5 Network Adapter ECB6250 User Guide

[Home](#) » [Actiontec](#) » Actiontec MoCA 2.5 Network Adapter ECB6250 User Guide 

Actiontec MoCA 2.5 Network Adapter ECB6250 User Guide




This Quick Start Guide will walk you through the easy steps to connect your MoCA Network Adapter.

Contents

- [1 Step 1: Connect to your Modem/Router](#)
- [2 Step 2: Connect to your Device](#)
- [3 Tech Support](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Step 1: Connect to your Modem/Router




- **a:** Get one **MoCA Network Adapter**.
- **b:** Connect one **Ethernet Cable** from the **Network Adapter** to the **Modem/Router**.
- **c:** Connect one **Splitter** to the **Coax Cable** coming from the **Coax Outlet** on the wall.
- **d:** Connect one **Coax Cable** from the **Splitter** to the Coax In port on the **Network Adapter**.

Note: If you have a TV or set top box near your modem/router, connect a coax cable from the splitter to the TV or set top box.

- **e:** Connect the second **Power Adapter** (External, 5V DC, 2A made by APD, Model #WB-10E05FU) to the **Network Adapter** and to **Power Outlet**.
- **f:** Wait until the **Power** light on the front of the adapter is GREEN.
- **g:** When the **Coax LED** is GREEN on both adapters, your adapters are working.

Step 2: Connect to your Device



- **a:** Get one **MoCA Network Adapter**.
- **b:** Locate the device or access point (laptop, etc.) that needs to connect to the Internet. Connect one **Ethernet Cable** from the **Network Adapter** to the **Device**.
- **c:** Connect one **Splitter** to the **Coax Cable** coming from the **Coax Outlet** on the wall.
- **d:** Connect one **Coax Cable** from the **Splitter** to the Coax In port on the **Network Adapter**.

- **e:** Connect one Power Adapter to the Network Adapter and to a Power Outlet.
- **f:** Wait until the Power light on the front of the adapter is GREEN.
- **g:** IMPORTANT! If the Coax LED on the Network Adapter is already GREEN, you may have MoCA built in to your modem/router. Check the device you just connected. If it is connected to the Internet, you're done*. If the device does not connect to the Internet, continue to Step 2.

* You may use the 2nd adapter with another device or access point.

©2020 Actiontec Electronics, Inc.

Actiontec, Creative Solutions for the Digital Life, and the Actiontec logo are registered trademarks or trademarks of Actiontec Electronics, Inc., in the U.S. or other countries. All other names are properties of their respective owners. Product photo may differ from actual product. However, functionality remains as stated above. Specifications are subject to change without notice.


Congratulations! You've successfully connected your device to the Internet.
Additional MoCA Network Adapters may be purchased and connected to other devices needing an Ethernet connection and that are near a coaxial port.

Tech Support

For registration or access to user manuals, wall-mount templates, software updates, etc. visit our webpage:

www.actiontecsupport.com/ecb6250

Documents / Resources

 <p>The Quick Start Guide will walk you through the easy steps to connect your MoCA Network Adapter.</p>	<p>Actiontec MoCA 2.5 Network Adapter ECB6250 [pdf] User Guide MoCA, 2.5, Network, Adapter, Actiontec, ECB6250</p>
---	--