



Actiontec MoCA Network Adapters ECB7250 KIT User Guide

[Home](#) » [Actiontec](#) » Actiontec MoCA Network Adapters ECB7250 KIT User Guide 

Actiontec®

Quick Start Guide
MoCA Network Adapters



ECB7250 KIT

This Quick Start Guide will walk you through the easy steps to connect your MoCA Network Adapters.

Congratulations! You've successfully connected your device to the Internet.

Additional MoCA Network Adapters may be purchased and connected to other devices needing an Ethernet connection and that is near a coaxial port.

Contents

- 1 Package Contents:
- 2 Tech Support
- 3 Documents / Resources
 - 3.1 References
- 4 Related Posts

Package Contents:

- (2) MoCA Network Adapters
- (2) Ethernet Cables
- (2) Power Adapters
- (2) Coaxial Cables
- (2) Coaxial Splitters (External, 5V DC, 2A made by APD, Model #WB-10E05FU)

Tech Support

For registration or access to user manuals, wall-mount templates, software updates, etc. visit our webpage:

www.screenbeam.com/products/screenbeam-ecb7250

Step 1: Connect to your Modem/Router

a Get one **MoCA Network Adapter**.

b Connect one **Ethernet Cable** from the **Network Adapter** to the **Modem/Router**.

c Connect one **Splitter** to the **Coax Cable** coming from the **Coax Outlet** on the wall.


d Connect one **Coax Cable** from the **Splitter** to the **Coax In** port on the **Network Adapter**.

Note: If you have a TV or set-top box near your modem/router, connect a coax cable from the splitter to the TV or set-top box.

e Connect the second **Power Adapter** to the **Network Adapter** and to a **Power Outlet**.

f Wait until the **Power** light on the front of the adapter is **GREEN**

g When the **Coax** LED is **GREEN** on both adapters, your adapters are working.



Step 2: Connect to your Device

a Get one **MoCA Network Adapter**.

b Locate the device or access point (laptop, etc.) that needs to connect to the Internet. Connect one **Ethernet Cable** from the **Network Adapter** to the **Device**.

c Connect one **Splitter** to the **Coax Cable** coming from the **Coax Outlet** on the wall.


d Connect one **Coax Cable** from the **Splitter** to the **Coax In** port on the **Network Adapter**.

e Connect one **Power Adapter** to the **Network Adapter** and to a **Power Outlet**.

f Wait until the **Power** light on the front of the adapter is **GREEN**

g **IMPORTANT!** If the **Coax LED** on the **Network Adapter** is already **GREEN**, you may have MoCA built into your modem/router. Check the device you just connected. If it is connected to the Internet, you're done*. If the device does not connect to the Internet, return to Step 1.

* You may use the 2nd adapter with another device or access point.



Actiontec®

©2020 Actiontec Electronics, Inc.


Actiontec, Creative Solutions for the Digital Life, and the Actiontec logo are registered trademarks or trademarks of Actiontec Electronics, Inc., in the U.S. or other countries. All other names are properties of their respective owners.

Product photos may differ from actual products.

However, functionality remains as stated above. Specifications are subject to change without notice.

PN 0530-0857-000

Documents / Resources

	Actiontec MoCA Network Adapters ECB7250 KIT [pdf] User Guide Actiontec, MoCA, Network Adapters, ECB7250, KIT
---	---

References

- [SB ScreenBeam](#) | [ECB7250](#) | [ScreenBeam](#)