

Active Ventilation RSV-3-WT 6 Round Soffit Vent Instructions

[Home](#) » [Active Ventilation](#) » Active Ventilation RSV-3-WT 6 Round Soffit Vent Instructions 

Working at Active Ventilation Products | Glassdoor

Active Ventilation Products, Inc.

Installation Instructions

Round Soffit Vent

Model: RSV-3

Diameter: 3"

Contents

1 [RSV-3-WT 6 Round Soffit Vent](#)


2 [Round Soffit Vent Installation Instructions](#)

3 [Documents / Resources](#)

3.1 [References](#)


RSV-3-WT 6 Round Soffit Vent

Angled View




- Net Free Area (NFA) = 1.74 sq in

Side View



Round Soffit Vent Flashing Detail



Round Soffit Vent Installation Instructions


1. Cut a 3" hole into the soffit using a hole saw.
2. Insert the vent into the hole in the soffit.
3. Attach the mounting plate onto the soffit using 4 screws to secure the soffit vent in place.

* Make sure the opening of the louvers are facing the house

** Recommended Screw: #8 x 1" Sheet Metal Screw (Screws not included)

Website: roofvents.com
 Email: sales@roofvents.com
 8/30/2022

Documents / Resources



[Active Ventilation RSV-3-WT 6 Round Soffit Vent](#) [pdf] Instructions
 RSV-3-WT 6 Round Soffit Vent, RSV-3-WT 6, Round Soffit Vent, Soffit Vent, Vent

References

-  [Roof Vents, Solar Attic Fans, Gravity Vents, Static Vents, Vent Caps](#)

-  [Roof Vents, Solar Attic Fans, Gravity Vents, Static Vents, Vent Caps](#)

Manuals+.