



# Active Ventilation VPC-6-WT Vent Pipe Cap Instruction Manual

[Home](#) » [Active Ventilation](#) » **Active Ventilation VPC-6-WT Vent Pipe Cap Instruction Manual** 

## Contents

- [1 Active Ventilation VPC-6-WT Vent Pipe Cap](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Dimension](#)
- [5 Installation Instructions](#)
- [6 CONTACT](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

## Active Ventilation

### Active Ventilation VPC-6-WT Vent Pipe Cap




### Product Information

The Active Ventilation Products Vent Pipe Cap Model VPC-6 is a all-aluminum cap designed to fit over an existing 6-inch diameter vent pipe. The cap is constructed with a thickness of 0.025 inches (0.635 mm) and features screws on top for easy attachment to the pipe. The product is manufactured by Active Ventilation Products, Inc., a company that specializes in roof ventilation solutions.

## Product Usage Instructions

1. Slide the Vent Pipe Cap over the existing vent pipe.
2. Observe the screws located on top of the cap and use them as a pattern to attach the cap to the pipe.
3. To secure the cap, attach it to the pipe using a #8 self-tapping sheet metal screw.
4. A total of three screws are needed for installation.
5. The recommended installation screw is a #8 x 1/2 Sheet Metal Screw.
6. Note that screws are not included with the product.


## Dimension



## Installation Instructions

- **Vent Pipe Cap Model:** VPC-6 Diameter: 6"

## Flashing Detail & Instructions



1. Slide the Vent Pipe Cap over the existing pipe.
2. Observe the screws located on top of the vent. Use this as a pattern to attach the vent to the pipe.
3. To secure the vent, attach the vent to the pipe using a #8 self-tapping sheet metal screw.

4. Total number of screws needed = 3
5. Recommended installation screw: #8 x 1/2" Sheet Metal Screw
6. Screws not included.


All Aluminum Construction, Thickness = 0.025" [0.635 mm]

## CONTACT

Website: [roofvents.com](http://roofvents.com) "

Email: [sales@roofvents.com](mailto:sales@roofvents.com)

## Documents / Resources



[Active Ventilation VPC-6-WT Vent Pipe Cap](#) [pdf] Instruction Manual  
VPC-6-WT, VPC-6, VPC-6-WT Vent Pipe Cap, Vent Pipe Cap, Pipe Cap, Cap

## References

-  [Roof Vents, Solar Attic Fans, Gravity Vents, Static Vents, Vent Caps](#)