

# **ACTIVE VPC-4 Vent Pipe Cap Instruction Manual**


Home » ACTIVE » ACTIVE VPC-4 Vent Pipe Cap Instruction Manual ™

#### **Contents**

- 1 ACTIVE VPC-4 Vent Pipe
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Installation Instructions**
- **5 Documents / Resources** 
  - **5.1 References**
- **6 Related Posts**



# **ACTIVE VPC-4 Vent Pipe Cap**



#### **Product Information**

The Active Ventilation Products, Inc. Vent Pipe Cap Model: VPC-4 is an all-aluminum construction product with a thickness of 0.025 [0.635 mm]. It is designed to provide ventilation to the roof through pipes with a diameter of 4 inches. The product is sold through the roofvents.com website and can be contacted through sales@roofvents.com.

#### **Product Usage Instructions**

- 1. Slide the Vent Pipe Cap over the existing pipe.
- 2. Observe the screws located on top of the vent. Use this as a pattern to attach the vent to the pipe.
- 3. To secure the vent, attach the vent to the pipe using a #8 self-tapping sheet metal screw.
- 4. Total number of screws needed = 3
- 5. Recommended installation screw: #8 x 1/2 Sheet Metal Screw
- 6. Screws not included.


**Note:** The flashing detail & instructions are not provided in this section of the manual. Please refer to the relevant section for the same.

#### **Installation Instructions**


Vent Pipe Cap Model: VPC-4

Diameter: 4"






### Flashing Detail & Instructions



- 1. Slide the Vent Pipe Cap over the existing pipe.
- 2. Observe the screws located on top of the vent. Use this as a pattern to attach the vent to the pipe.
- 3. To secure the vent, attach the vent to the pipe using a #8 self-tapping sheet metal screw.
- 4. Total number of screws needed = 3
- 5. Recommended installation screw: #8 x 1/2" Sheet Metal Screw
- 6. Screws not included.

\* All Aluminum Construction, Thickness = 0.025" [0.635 mm]

Website: <u>roofvents.com</u> Email: <u>sales@roofvents.com</u>



# ACTIVE VPC-4 Vent Pipe Cap [pdf] Instruction Manual

VPC-4-BL, VPC-4, VPC-4-WT, VPC-4-BR, VPC-4-WD, VPC-4-GR, VPC-4 Vent Pipe Cap, VPC -4 Pipe Cap, Vent Pipe Cap, Vent Cap, Cap

#### References

• Roof Vents, Solar Attic Fans, Gravity Vents, Static Vents, Vent Caps

Manuals+,