Manuals+ — User Manuals Simplified.

actto Bluetooth and Wireless Keypad User Manual

Contents

actto Bluetooth and Wireless Keypad

Product name

1. Status LED indicator
2. Battery cover
3. Power (ON-OFF) button
4. Mode button
5. Mode LED indicator
6. Receiver storage home
7. Receiver

How to insert batteries

1. Open the battery cover on the bottom of the keypad.
2. Insert 1 AAA battery correctly by checking the (+-) anode.
3. Close the battery cover after inserting the battery. (A "click' indicates that it is fully closed.)

Power (ON/OFF) button

- **Power ON:** Slide the power button on the bottom of the keypad to ON to turn it on.
- **Power OFF:** Slide the power button on the bottom of the keypad to OFF to turn off the power. Reduce the battery's power consumption.

LED color

- **Status LED indicator:**
    1. When Num Lock is pressed (White)
    2. When the battery is low (Red) – blinks for 10 seconds when using the keypad
- **LED by mode:** Wireless channel (Green)/ Bluetooth channel 1 (Blue)/ Bluetooth channel 2 (Blue)

Power saving mode

1. **Standby mode:** Standby mode is activated when the keypad is not in use
2. **Sleep mode:** Approximately ten minutes after entering standby mode, switch to sleep mode
3. **Operation mode:** Standby mode is deactivated by using the keypad

Change mode (use of 3 devices)

Press the back mode button to change the mode. (2 Bluetooth +1 wireless):

1. **Wireless Channel:** Green LED
2. **Bluetooth Channel 1:** Blue LED "ANBK-01BT1"
3. **Bluetooth Channel 2:** Blue LED, "ANBK-01BT2"

How to connect wirelessly

1. Press the back mode button to select "Wireless Channel (Green LED)".
2. Plug the USB receiver into a USB port such as a computer or laptop.
3. You can use it immediately after the setting is complete. (PLUG & PLAY)

Bluetooth connection method

1. Press the back mode button to select "Bluetooth Channel 1 (Blue)" or "Bluetooth Channel 2 (Blue)"
   To enter pairing mode, press the mode button for about 3 seconds.
2. Activate the Bluetooth function of the device you want to connect to.

3. Select "ANBK-01BT1" or "ANBK-01BT2" after connecting the device to the network.

  - The device is automatically recognized without the need to install additional drivers or utilities.
  - The range is up to 10 meters. (There may be differences depending on the user environment.)

FEATURE

Bluetooth 5.2
Max. 10m

2.4GHz
Max. 10m

Use of 3 devices
Bluetooth 1,2 mode
wireless mode

**Intuitive
LEDs**

**Asynchronous
number lock**

Power button
ON/OFF

CAUTIONS

- The user manual should be read before using the keypad.
- In order to maximize battery life, please turn off the power when traveling or not using for a long period of time.
- It is recommended that you replace the batteries if the keypad malfunctions.
- There is no need to install additional drivers and utilities.
- (Bluetooth) Frequency confusion may occur if there are many Bluetooth devices in the vicinity.
  - Keep other Bluetooth devices at a distance.
- (Wireless) Reception may be poor if an obstruction is present between the wireless receiver and the keypad.
- Do not use in places with high temperatures and humidity or in dusty places.
- Be careful not to drop the keypad or to receive a strong blow.
- Be careful not to injure your hands when opening the package.
  - There is a risk of injury from the package.
- Do not assemble or dismantle disassemble the product.
- The specifications of products are subject to change without notice in order to improve their performance.

FCC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant

to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment o and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

www.actto.com

Wireless

Bluetooth

Documents / Resources

	actto Bluetooth and Wireless Keypad [pdf] User Manual ABTM-01R, ABTM01R, 2A3GJ-ABTM-01R, 2A3GJABTM01R, Bluetooth and Wireless Keypad, Bluetooth Keypad, Wireless Keypad, Keypad