




ADDAC System ADDAC218 Attenuverters Eurorack Module User Guide

[Home](#) » [ADDAC System](#) » ADDAC System ADDAC218 Attenuverters Eurorack Module User Guide 



ADDAC
System

**ADDAC218 ATTENUVERTERS
USER'S GUIDE
Revision.01
December.2020**



Welcome to:

Contents

[1 DESCRIPTION](#)

[2 CONTROLS DESCRIPTION](#)

[3 ADDAC218 ATTENUVERTERS SIGNAL FLOW
DIAGRAM](#)

[4 Documents / Resources](#)

[5 Related Posts](#)

DESCRIPTION

Another addition to our ADDAC200's CV Utilities

This module features 3 independent Attenuverters each with it's input, output and 13mm knob
White areas allow the user to write down what is connected to each channel.

Channel 1 is normalled to Channels 2 and 3.


Specs:

4hp




$\pm 40\text{mA}$

2.5cm deep

CONTROLS DESCRIPTION



ADDAC218
ATTENUVERTERS SIGNAL FLOW DIAGRAM



For feedback, comments or problems please contact us at: addac@addacsystem.com

Documents / Resources

	ADDAC System ADDAC218 Attenuverters Eurorack Module [pdf] User Guide ADDAC218, Attenuverters Eurorack Module
---	--