



## Adexa YA-809 Bloating Machine User Manual

[Home](#) » [Adexa](#) » Adexa YA-809 Bloating Machine User Manual 

*Adexa YA-809 Bloating Machine User Manual*

# YA-809 BLOATING MACHINE USER MANUAL

Read this manual carefully prior to use Technology is subject to change without further notice

**WARNING:** Our Company will not be responsible for any accidents caused by disobeying operation rules and neglecting operation items.

This product has features of original and larruping design, reasonable structure, small volume, beautiful figure, even rotate speed, less noise, big output moment, big capacity, and good containment, fast bloating and saving energy. It can bloat many kinds of meat and other food with features of no distortion, even taste and good colour.

## Contents

- 1 A. Function
- 2 B. Basic parameter
- 3 C. Usage condition
- 4 D. Transportation and storage
- 5 E. Attention of installation
- 6 F. Ways of operation
- 7 G. Cleaning and maintenance
- 8 I Troubleshooting
- 9 Documents / Resources
- 10 Related Posts

### A. Function

1. This product has time setting controller, each time it bloats meat for about twelve minuets.
2. There is waterproof apparatus (device) in electric part. 3. This product with the function of the vacuum curing .

### B. Basic parameter

CODE	VOLTAGE	FRQUENCY	POWER	SPEED RATE	DIMENSION	VOLUME
YA-809	220~240	50~60HZ	330W	29	953*660*914	40L

### C. Usage condition

The altitude is not higher than 1000M;temperature of environment is not higher than 40;Voltage of power supply is not over 5%; frequency of power supply is not over $\pm 1\%$ ; Capacity is not more than 30KG.

### D. Transportation and storage

During transpiration, the machine should be careful handled and prevent from shaking, collision and being cover. It should be put in a ventilated warehouse without causticity gas. And it should not be put up side down.

### E. Attention of installation

1. This machine should be placed on a stable place, its two sides are recommended to be put more than 10CM from any obstacles. Operator should be away 30cm from the machine while it is running in case of the machine hurts people.
2. Please check whether the rotating container is impacted, if not, do not turn on the machine.
3. Do not put the hand on the rotating container while the machine is working. Do not open the cover of the container until it stops rotating.
4. The earth wire of this machine must be done by professionals. Do not let people who are not electricians open the cover of electric box in the case of getting an electric shock
5. The electric connection of this machine must be done by professionals. Do not let people who are not electricians open the cover of electric box in the case of getting an electric shock.

## F. Ways of operation

1. Uncover the cover of container by unplugs the handle upwards and circumvolves 90°and lifts it up. Put food and materials of bloating into the container and cover it(Mind: level with rubber).Then rotate 90°and press handle counter direction till it is impacted
2. Turn on power switch and press the START button: the machine runs. Press the STOP button, the machine stops working. If not, the machine will stop in 12minute automatically. Open the cover and pour the completed food out of the container.
3. Ask the professional to adjust time for bloating different food. Open the cover of electric box and adjust time relay to different time position according to the time of bloating.

## G. Cleaning and maintenance

1. Cut off power while cleaning in case of accident.
2. Clean the surface and container with cleaner that is not corrosive after a day working.

**Warning: Do not spray water on electric button**

## I Troubleshooting

Troubles	Causes	Solutions
Stop rotating	1. Fuse is burned 2. Motor is burned 3. Transmission strap is broken. 4. Overload.	Change  Lighten load
It can not stop rotating automatically after getting through power 12minutes	Time relay is broken	Repair or change
There is some mechanical sound	1. There is no lube in reducer of electric box 2. Out transmission rubber is damaged	Infuse lube  Change transmission rubber,
Container is leaked	Sealed ring is not sealed or used for too long	Change sealed ring

## Documents / Resources

<p>YA-809 BLOATING MACHINE USER MANUAL</p> <p><small>Read the manual carefully, please do not touching a voltage change without safety device</small></p>	<p><a href="#">Adexa YA-809 Bloating Machine</a> [pdf] User Manual YA-809, Bloating Machine, YA-809 Bloating Machine, Commercial Marinating Machine</p>
---	---