

Adjustable Roller 43164387 Skate Print colour Frant User Manual

Home » Adjustable Roller » Adjustable Roller 43164387 Skate Print colour Frant User Manual



Contents

- 1 Adjustable Roller 43164387 Skate Print colour **Frant**
- **2 MAINTENANCE**
- **3 SHOE SIZE ADJUSTMENT**
- 4 Documents / Resources
- **5 Related Posts**

ADJUSTABLE ROLLER

Adjustable Roller 43164387 Skate Print colour Frant



43164387, 43164394, 43164400 Adjustable size PU wheels - ABEC-7 Bearings WARNING! PROTECTIVE EQUIPMENT SHOULD BE WORN. NOT TO BE USED IN TRAFFIC.

CAUTION!


- · Read the manual carefully before using your new skates
- Prior to each use, please check that all screws and connections are tightened. Make sure that the brake, wheels and bearings are in good condition.
- Self-locking nuts and other self-locking fixings may lose their effectiveness after used.
- Protective equipment should be worn. We recommend you to wear a helmet, wrist, knee and elbow protectors
 and reflective clothing when needed.
- Use the skates with caution to avoid falls or colisions causing injury to the user or anyone else. Do not ride your skates in sloping areas.
- Not to be used in traffic. Always foliow and obey all local trafic laws and regulations. Stay away from motor vehicles and watch out for pedestrians.
- Never allow yourself to be pulled along by a motorized vehicle.
- · Ride your skates in daylight.
- · Avoid skating in sand, water or dirt
- Never leave your skates in extreme high/low temperatures as it might damage the skates.
- Never let children use the skates without adult supervision.
- · Store the product indoors.
- DO NOT make any modifications to this product.
- Keep the instruction for future reference+skate maintenance.
- Note to remove any sharp edges created through use.

MAINTENANCE

- Prior to each use it is important to check that all screws are tightened. Check that the wheels roll properly and that the bearings are in good condition.
- Please rotate the bearings and wheels to see whether they are workable, and do some adjustments or add lubricant if its needed after the first 2 weeks of use
- The wheels and wheel bearings may become worn out after regular use and can be changed easily. A special key, available in most tool shops, can be used to remove the ball bearing. Clean the ball bearings using a clean, dry cloth. Lubricate the bearings if necessary.
- On a regular bases we recommend to swap the wheels around, to keep all wheels in good condition and to prevent irregular wear.
- Try to anticipote braking and the higher speed, the greater braking distance. Check the brake pad regularly and replace if necessary. To use the brake, bend your knees deeply and put your legs in a staggered position with the brake skate in front. Carefuly lift the tip of the foot with the brake skate and put some weight on the heel to stop.
- This roller skate meets EN13899 Class A standards. Suitable for users up to 100kg.



SHOE SIZE ADJUSTMENT



BRAKING

To apply the brake, lean backwoard from the waist lift your braking skate up tilting it forward and exert pressure slowly with uour heel while bending your other knee full stop

STARTING OUT

Bend your knees slightly and push off easily to the back and side with one skate as you glide forward on the other skate. Then bring your book skate forward so it is even with your front skate and repeat. Always remember to bend your knees slightly. Turning is achieved by gliding and bringing your knees together and leaning in the direction you want to ga. Practice this motion both left and right

RULES OF THE ROAD

Always wear your protective gear: helmet, wrist guards, knee and elbow pads. Leam skating basics such as braking and burning before going out on th open trail. Stay awoy trom water. oll, debris, sand and uneven or broken pavement. Avoid areas with traffic. Never hitch yourself along motorized vehicles. Stay olert! Always be coutious of controling the speed of your skates. Stay in control. Before using the skates, read the trafia regulations of the town or city. state or country where you are.

MADE IN CHINA FOR AU NZ; IMPORTED FOR KMART STORES IN ÄUSTRALIA AND NEW ZEALAND

Documents / Resources



Adjustable Roller 43164387 Skate Print colour Frant [pdf] User Manual 43164387 Skate Print colour Frant, 43164387, Skate Print colour Frant, colour Frant

Manuals+,