



adonit PD-4A1C 30W World Travel Adapter with 4 USB and Type-C User Manual

[Home](#) » [adonit](#) » adonit PD-4A1C 30W World Travel Adapter with 4 USB and Type-C User Manual 


adonit PD-4A1C 30W World Travel Adapter with 4 USB and Type-C User Manual



Contents

- 1 **PRODUCT OVERVIEW**
 - 1.1 SPECIFICATIONS
- 2 **APPLICABLE OUTLETS**
- 3 **POLE UNEARTHED DEVICES**
- 4 **USB DEVICES**
- 5 **HOW TO USE THE ADAPTER**
 - 5.1 Features
 - 5.2 Attentions
- 6 **REPLACEMENT OF THE FUSE**
- 7 **COMPATABLE COUNTRIES**
 - 7.1 EU PLUG
 - 7.2 AUS PLUG:
 - 7.3 USA PLUG
- 8 **UK PLUG**
- 9 **Documents / Resources**
- 10 **Related Posts**

PRODUCT OVERVIEW





SPECIFICATIONS


- **AC Input:** 100V-250V, 50/60Hz
- **Rating:** 100-250Vac 10A Max , 2500W Max
- **Single Port Output:**
USB-C Output: 5V $\overline{\text{---}}$ 3A, 9V $\overline{\text{---}}$ 3A, 12V $\overline{\text{---}}$ 2.5A, 15V $\overline{\text{---}}$ 2A, 20V $\overline{\text{---}}$ 1.5A
USB-A Output: 5V $\overline{\text{---}}$ 2.4A Max
- **Multi-port Output :**
USB-C Output: 5V $\overline{\text{---}}$ 3A Max
USB-A Output: 5V $\overline{\text{---}}$ 4A(Total), 2.4A Max Per Port
Total DC Output: 30W
- **Dimensions:** 71mm x 54mm x 53mm
- **Weight:** 136g
- **Operating Temperature:** 0°C – 35°C

APPLICABLE OUTLETS


1. Adapter can accept Type A, B, C, E, F, G, I, J, L, N plugs.




Please notice that type D, H, K, M and O plugs are not accepted.




Type D




Type H



Type K




Type M




Type O


2. Adapter can plug into Type A,B,C,D,E,F,G,H,I,J,K,L,M,N and O outlets.




Type A




Type B




Type C




Type D




Type E




Type F




Type G



Type H




Type I




Type J




Type K




Type L



Type M



Type N



Type O

POLE UNEARTHED DEVICES

The product is suitable for use with most electronic devices up to 2500W at 250V and 1000W at 100V. It can be used with a multitude of appliances such as: Laptops, Small travel hair dryers, Travel irons, Electric fan, Table lamp, Electric razors, etc.

Please check the safety data sheet or data plate on the device to find this information before plugging it in.

- **Laptops**



- **Small travel hair dryers**



- **Travel irons**



- **Electric fan**



- **Table lamp**



- **Electric razors**



USB DEVICES

Camera, Smartphone, Tablet, Portable Game Console, Bluetooth speaker, Power bank, **etc.**

- **Cameras**



- **Smartphones**



- **Tablets**



- **Portable Game Console**



- **Headsets**



- **Power banks**



HOW TO USE THE ADAPTER


Features

Built-in multi-nation plugs can be selected to fit all outlets in different countries. Safety function switch ensure only one plug energized.

Attentions


1. Please make sure that the button is reset when the button is pushed out and retracted to the bottom, and if the button is not reset, it means that the pug has not been pushed in place and will affect the normal use.
2. Only one plug-type can be used at one time by sliding the knob selection, other plug-pins are locked automatically.

Slightly press the button and slide to the down for USA plug completely as shown. make sure the contact blades are turned to the parallel position. Recover the plug: press and hold the “USA” button to release and continue to pull up, until the plug completely pull the top and then release the button, then the button will reset and lock the plug.



USA


Slightly press the button and slide to the down for AUS plug completely as shown .make sure the contact blades are turned to the parallel position.



AU


Recover the plug: press and hold the “AUST” button to release and continue to pull up, until the plug completely pull the top and then release the button, then the button will reset and lock the plug.

Slightly press the button and slide to the down for UK plug completely as shown .Pull out the insulated ground pin from the housing. Recover the plug: press and hold the “UK” button to release and continue to pull up, until the plug completely pull the top and then release the button, then the button will reset and lock the plug.



UK


Slightly press the button and slide to the down for EUROPE plug completely as shown .make sure the contact blades are turned to the parallel position. Recover the plug: press and hold the “EUROPE” button to release and continue to pull up, until the plug completely pull the top and then release the button, then the button will reset and lock the plug.



EUROPE

REPLACEMENT OF THE FUSE

1. Take out **1**
2. Take out **2**, and put 0 into the original position of **2**, the adapter could work again.
3. **You also could change new fuse. standard:**
250V 10A, BS1362 approved.



Notes:

1. You should remove all the device before you change the new fuse.
2. Please confirm whether there are water flowed out from the access equipment in the power rating.
3. Please confirm whether the product is wet and there is water flowed out

CAUTION

- Before use, please read this instruction carefully!
This product does not convert voltage(AC-AC), in order to avoid possible damage to your device or other safety hazards, please make sure the power outlet you intend to use has the proper voltage to run your device before using this adapter.
- Each country has its own regulations regarding the use of travel adapters, please check in each country before use.
- No grounding, This product is for use with unearthed or double insulated appliances only.
- Indoor use only.

COMPATABLE COUNTRIES

EU PLUG

- **A** Albania
Algeria
Angola
Argentina
Austria

Azores

- **Balearic Islands**

Bangladesh

Belgium

Bolivia

Bosnia

Brazil

Bulgaria

Burkina Faso

Burundi

- **Cameroon**

Canary Island

Cape Verde

Central African Republic

Channel Islands

Chile

Comoros

Congo

Croatia

Cote d' Ivoire

Cyprus

- **Denmark**

Djibouti

- **Egypt**

El Salvador

Equatorial Guinea

Eritrea

Faeroe Islands

Finland

France

- **Gabon**

Germa

Gibraltar

Greece

Greenland

Guadeloupe

Guinea

Guinea-Bissau

- **Hungary**

- **Iceland**

India

Indonesia

Iran

Iraq

Israel

Italy

- **Kazakhstan**

Korea

Kuwait

- **Laos**

Lebanon

Lithuania

Luxembourg

- **Macedonia**

Madagascar

Madeira

Mali

Martinique

Mauritania

Mauritius

Monaco

Morocco

Mozambique

Myanmar

- **Nepal**

Netherlands

Niger

Norway

- **Oman**

Pakistan

Paraguay

Peru

Philippines

Poland

Portugal

- **Romania**

Russia

Rwanda

- **Senegal**

Somalia

Spain

Sudan

Suriname

Sweden

Switzerland

Syria

- **Thailand**

Togo

Tunisia

Turkey

- **Uruguay**

- **Vietnam**

- **Zambia**

AUS PLUG:

- **American Samoa**

Argentina

Australia

- **China**

- **El Salvador**

- **Guatemala**

- **Kiribati**

- **Nauru**

New Zealand

- **Panama**

Papua New Guinea

- **St. Vincent**

- **Tajikistan**

Tonga

- **Uruguay**

USA PLUG

- **American Samoa**

Anguilla

Antilles

Aruba

- **Bahamas**

Bangladesh

Barbados

Bermuda

Bolivia

Brazil

- **Cambodia**

Canada

Cayman Islands

China

Colombia

Costa Rica

Cuba

- **Ecuador**
El Salvador
- **Guam**
Guatemala
Guyana
- **Haiti**
Honduras
- **Japan**
Jamaica
- **Laos**
Lebanon
Liberia
- **Maldives**
Mexico
Micronesia
Montserrat
- **Netherlands**
Nicaragua
Niger
- **Okinawa**
- **Panama**
Peru
Philippines
Puerto Rico
- **St. Vincent**
Saudi Arabia
- **Tahiti**
Taiwan
Thailand
United States
- **Venezuela**
Vietnam
Virgin Islands(US&British)
- **Yemen**

UK PLUG

- **Bahrain**
Bangladesh
Belize
Botswana
Brunei
- **Cameroon**

Channel Islands

Cyprus

- **Dominica**

- **El Salvador**

- **Gambia**

Ghana

Gibraltar

Grenada

Guatemala

Guyana

- **Hong Kong**

- **Iraq**

Ireland

Isle of Man

- **Jordan**

- **Kuwait**

- **Lebanon**

- **Macau**

Malawi

Malaysia

Maldives

Malta

Mauritius

Myanmar

- **Nigeria**

- **Qman**

Qatar

- **St. Lucia**

St. Vincent

Saudi Arabia

Seychelles

Sierra Leone

Singapore

- **Tanzania**

- **Uganda**

United Arab Emirates

United Kingdom

- **Vietnam**

- **Yemen**

- **Zambia**

Zimbabwe



CAUTION

Misuse can lead to electrical shock.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.



World Travel Adapter With 4 USB & Type-C

Documents / Resources



[adonit PD-4A1C 30W World Travel Adapter with 4 USB and Type-C](#) [pdf] User Manual
PD-4A1C, 30W World Travel Adapter with 4 USB and Type-C