


ADVANCE
WTX-700 EVO Receiver



Advance WTX-700 EVO Receiver User Manual

[Home](#) » [Advance](#) » Advance WTX-700 EVO Receiver User Manual 

Contents

- 1 Advance WTX-700 EVO Receiver User Manual
- 2 TO FINE-TUNE, FOLLOW THOSE 3 STEPS
- 3 DECLARATION OF CONFORMITY
- 4 References

ADVANCE

Advance WTX-700 EVO Receiver User Manual



TO FINE-TUNE, FOLLOW THOSE 3 STEPS



1. Connect the WTX-700 to an auxiliary input of your HiFi amplifier or AV receiver. Plug on an outlet the power supply adapter. The blue LED of your WTX-700 is flashing.
2. Go to the Bluetooth Manager of your iPhone, iPod touch, iPad, tablet, smartphone, PC, or MAC computer, then go to the bluetooth settings.

3. You will see a new bluetooth connection under the WTX-700 name. Confirm that you chose it, after a few seconds, your audio device is paired with the WTX-700.
4. If pairing is ok, then, the blue LED of the Air amplifier will be fixed. You don't need any PIN code confirmation.
5. Your WTX-700 is now connected and ready to play music in HD with APTX HD! Just play music on your device as you normally would and the sound will come out of your HiFi system.
6. If you move out of range or turn off the Bluetooth feature on your audio device, the Bluetooth Music Receiver will disconnect from your device.
7. To reconnect, simply access the Bluetooth Manager on your device and select the WTX-700 connection.

DECLARATION OF CONFORMITY

We declare under our sole responsibility that this product, to which this declaration relates, conforms with the council EMC directive 2014/30/EU, the LVD directive 2014/35/EU, the RoHS2 2011/65/EU and RED 2014/53/EU .Advance Paris Sarl, 13 rue du coq gaulois – 77170 Brie Comte Robert – France

Download PDF: [Advance WTX-700 EVO Receiver User Manual](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.