

ADVATEK LIGHTING E4-S Mk3 Professional Pixel Control User Guide

Home » ADVATEK LIGHTING » ADVATEK LIGHTING E4-S Mk3 Professional Pixel Control User Guide





PixLite E4-S Mk3 Quick Start Guide

Contents


- 1 Physical Connections
- 2 Startup & Network

Connection

- 3 Further Information
- 4 Advatek SHOWTime
- **5 Warranty Registration**
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts

Physical Connections

In order to connect to the PixLite E4-S Mk3, there must be a working power supply between 5 – 24Vdc connected to the power input, which is the small screw terminal marked "+" & "-". The screws should be loosened for wire insertion and then tightened again, providing a highly robust and secure connection. Polarity for the connector is clearly marked on the lid.



Startup & Network Connection

2.1 - Startup

Upon startup for the first time, the PixLite will be using DHCP/AutoIP and the status LED will flash green, indicating normal operation. If you have a router, then DHCP will automatically assign an IP address to both the PixLite and your computer.

No Router? No Problem. Simply connect the PixLite directly to your computer, and open Advatek Assistant 3.

2.2 - Advatek Assistant 3

The easiest method for connecting to the PixLite E4-S Mk3 is by launching Advatek Assistant 3 to discover the device. Advatek Assistant 3 can be downloaded and installed, using the URL below: www.advateklighting.com/advatek-assistant-3

Any active PixLite devices on the network will automatically be discovered and displayed. Double click to open its Management Interface, and begin configuring your new PixLite E4-S Mk3.




Figure 2: Advatek Assistant 3

Further Information

For a more in-depth understanding of the device, including physical installation, electrical connections, network

connections, operation, and specifications, you should consult the PixLite E4-S Mk3 User Manual: www.advateklighting.com/downloads/user-manuals/pixlite-e4-s-mk3

Advatek SHOWTime

Advatek SHOWTime ™ unleashes the potential of Advatek PixLite® Mk3 devices to independently drive light shows without a computer or any source of live data.

SHOWTime™ allows users to record and play back pixel shows from the PixLite E4-S Mk3 using the inbuilt microSD slot. Design your own breathtaking pixel shows, record them directly onto the microSD card and play them back as many times as you wish.

SHOWTime[™] also unlocks the ability to create up to 25 powerful triggers and use advanced intensity controls to enable true standalone behavior and enhance live environments.

Experience a new level of control with the dual-user login feature and a dedicated SHOWTime™ Dashboard. Now, operators can access real-time playback and device control through the SHOWTime™ Dashboard, amplifying the flexibility of PixLite Mk3.

For more information, download the PixLite Mk3 Management Guide here: www.advateklighting.com/product-help/pixlite/mk3/management-quide

Warranty Registration

For your complete peace of mind, this PixLite E4-S Mk3 comes with an industry leading extended warranty period of 5 years, subject to registration.

Please register your Advatek PixLite® Mk3 product using the link below. <u>www.advateklighting.com/warranty-registration</u>

All products need to be used and installed in accordance with their designed purpose and operating environment. See our Store Policy below for full terms and conditions on returns, faults and warranty claims.

www.advateklighting.com/store-policy



PixLite E4-S Mk3 Quick Start Guide V20230823

Documents / Resources



ADVATEK LIGHTING E4-S Mk3 Professional Pixel Control [pdf] User Guide E4-S Mk3, E4-S Mk3 Professional Pixel Control, Professional Pixel Control, Control ol

References

^ Professional pixel control lighting solutions

- Advatek Assistant 3 free application
- ^ Download Advatek Lighting user manuals
- ^ Download Advatek Lighting Management & Configuration Guides
- ^ Advatek Lighting warranty policy
- ^ Register your Advatek device

Manuals+,