



ADVATEK T8-S Mk3 Get Greater Impact User Guide

[Home](#) » [ADVATEK](#) » ADVATEK T8-S Mk3 Get Greater Impact User Guide 

Contents

- [1 ADVATEK T8-S Mk3 Get Greater Impact](#)
- [2 PixLite T8-S Mk3 Quick Start Guide](#)
- [3 Startup & Network Connection](#)
- [4 Physical Connections](#)
- [5 Startup & Network Connection](#)
- [6 Further Information](#)
- [7 Warranty Registration](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)

ADVATEK

ADVATEK T8-S Mk3 Get Greater Impact



PixLite T8-S Mk3 Quick Start Guide

- In order to connect to the PixLite T8-S Mk3, the IEC Power Input must be connected to a source of mains power (100-240V AC, 50/60Hz).

- An Ethernet cable should also be connected to either of the Ethernet Ports, allowing connection to a local network, or directly to a PC.


Startup & Network Connection

- Upon startup for the first time, the PixLite will be using DHCP/AutoIP and the status LED will flash green, indicating normal operation. If you have a router, then DHCP will automatically assign an IP address to both the PixLite and your computer.
- No Router? No Problem. Simply connect the PixLite directly to your computer, and open Advatek Assistant 3.

Physical Connections

- In order to connect to the PixLite T8-S Mk3, the IEC Power Input must be connected to a source of mains power (100-240V AC, 50/60Hz).
- An Ethernet cable should also be connected to either of the Ethernet Ports, allowing connection to a local network, or directly to a PC.

Figure 1: Connection Points



Startup & Network Connection


Startup

- Upon startup for the first time, the PixLite will be using DHCP/AutoIP and the status LED will flash green, indicating normal operation.
- If you have a router, then DHCP will automatically assign an IP address to both the PixLite and your computer.
- No Router? No Problem. Simply connect the PixLite directly to your computer, and open Advatek Assistant 3.

Advatek Assistant 3

- The easiest method for connecting to the PixLite T8-S Mk3 is by launching Advatek Assistant 3 to discover the device. Advatek Assistant 3 can be downloaded and installed, using the URL below:
www.advateklighting.com/advatek-assistant-3.
- Any active PixLite devices on the network will automatically be discovered and displayed.
- Double click to open its Management Interface, and begin configuring your new PixLite T8-S Mk3.

Figure 2: Advatek Assistant 3



The screenshot shows the Advatek Assistant 3 application window. It has a menu bar with 'File', 'Edit', and 'Help'. Below the menu is a 'Devices' section with a 'Clear' button and a refresh icon. The main area displays a table of discovered devices with columns for Nickname, Model, IP, MAC, and Firmware. Each row has a lock icon and a three-dot menu icon on the left.

	Nickname	Model	IP	MAC	Firmware
🔒	Entrance Arch	PixLite E4-S Mk3	192.168.2.145	E0:B6:F5:E0:12:CA	1.2.2
🔓	Default Nickname	PixLite A4-S Mk3	192.168.1.133	E0:B6:F5:E0:16:40	1.2.2
🔓	Sign - Outside Advertisement	PixLite E16-S Mk3	192.168.2.146	E0:B6:F5:E0:12:CB	1.2.2
🔓	Stage 1 - Left	PixLite A16-S Mk3	192.168.3.101	E0:B6:F5:E0:12:CC	1.2.2
🔒	Stage 1 - Right	PixLite A16-S Mk3	192.168.3.102	E0:B6:F5:E0:12:CD	1.2.2
🔓	Stage 2	PixLite T8-S Mk3	192.168.3.103	E0:B6:F5:E0:12:CE	1.2.2
🔓	Themepark Ride East	PixLite A4-S Mk3	10.0.0.170	E0:B6:F5:E0:12:CF	1.2.2
🔓	Themepark Ride West	PixLite A4-S Mk3	10.0.0.171	E0:B6:F5:E0:12:D0	1.2.2

Further Information

- For a more in-depth understanding of the device, including physical installation, electrical connections, network connections, operation, and specifications, you should consult the PixLite T8-S Mk3 User Manual:
www.advateklighting.com/downloads/user-manuals/pixlite-t8-s-mk3.

Advatek SHOWTime

•



Advatek SHOWTime™ unleashes the potential of Advatek PixLite® Mk3 devices to independently drive light shows without a computer or any source of live data.


- SHOWTime™ allows users to record and play back pixel shows from the PixLite T8-S Mk3 using the inbuilt microSD slot. Design your own breathtaking pixel shows, record them directly onto the microSD card and play them back as many times as you wish.
- SHOWTime™ also unlocks the ability to create up to 25 powerful triggers and use advanced intensity controls to enable true standalone behavior and enhance live environments.
- Experience a new level of control with the dual-user login feature and a dedicated SHOWTime™ Dashboard. Now, operators can access real-time playback and device control through the SHOWTime™ Dashboard, amplifying the flexibility of PixLite Mk3.

- For more information, download the PixLite Mk3 Management Guide here:
www.advateklighting.com/product-help/pixlite/mk3/management-guide.

Warranty Registration

- For your complete peace of mind, this PixLite T8-S Mk3 comes with an industry leading extended warranty period of 5 years, subject to registration.
- Please register your Advatek PixLite® Mk3 product using the link below.
www.advateklighting.com/warranty-registration.
- All products need to be used and installed in accordance with their designed purpose and operating environment.
- See our Store Policy below for full terms and conditions on returns, faults and warranty claims.
www.advateklighting.com/store-policy. www.advateklighting.com.

Documents / Resources

 <p>PixLite T8-S Mk3 Quick Start Guide 1 - Physical Connections</p>	<p>ADVATEK T8-S Mk3 Get Greater Impact [pdf] User Guide T8-S Mk3 Get Greater Impact, T8-S Mk3, Get Greater Impact, Greater Impact, Impact</p>
--	---

References

- ^ [Professional pixel control lighting solutions](#)
- ^ [Advatek Assistant 3 free application](#)
- ^ [Download Advatek Lighting user manuals](#)
- ^ [Download Advatek Lighting Management & Configuration Guides](#)
- ^ [Advatek Lighting warranty policy](#)
- ^ [Register your Advatek device](#)
- [User Manual](#)