



# ADVENT AKBWLBL15 Wireless Keyboard Instruction Manual

[Home](#) » [ADVENT](#) » ADVENT AKBWLBL15 Wireless Keyboard Instruction Manual 

## Contents

- [1 ADVENT AKBWLBL15 Wireless Keyboard](#)
- [2 Safety Warnings](#)
- [3 Unpacking](#)
- [4 Product Overview](#)
- [5 Installing the Batteries](#)
- [6 Activating the Keyboard](#)
- [7 Function Keys.](#)
- [8 Hints and Tips](#)
- [9 Specifications](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)

# ADVENT

**ADVENT AKBWLBL15 Wireless Keyboard**



## Safety Warnings

Read all the instructions carefully before using the unit and keep them for future reference. Retain the manual. If you pass the unit onto a third party, make sure to include this manual.

### Wireless Devices:

- Before boarding any aircraft or packing a wireless device in luggage that will be checked in, remove the batteries from the wireless device.
- Wireless devices can transmit radio frequency (RF) energy, whenever batteries are installed and the wireless device is turned on (If it has an On/Off switch).

### Battery-Powered Devices:





- Improper use of batteries may result in battery fluid leakage, overheating, or explosion.
- Released battery fluid is corrosive and may be toxic. It can cause skin and eye burns, and is harmful if swallowed.
- Do not disassemble the keyboard or remove any parts.
- Do not immerse the keyboard in water or any liquid.
- Do not use the keyboard close to heat sources or exposed to high temperatures.
- Do not use the keyboard where strong electromagnetic waves are present. Strong electromagnetic waves will cause damage to the keyboard.
- Keep the keyboard away from direct sunlight, moisture, dirt or abrasive chemical products (cleaning products etc).

### To Reduce the Risk of Injury:

- Keep batteries out of the reach of children.
- Do not heat, open, puncture, mutilate, or dispose of batteries in fire.
- Do not mix new and old batteries or batteries of different types.
- Do not allow metal objects to touch the battery terminals on the device; they can become hot and cause burns.

Thank you for purchasing your new product. We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues. Read all the safety instructions carefully before use and keep this instruction manual for future reference.


## Unpacking




- Main Unit
- Nano Dongle
- AAA Size Battery x 2
- Instruction Manual

## Product Overview

### Top View




## Bottom View



## Installing the Batteries

When battery is low, the LED indicator will flash continuously.


1. Remove the battery cover.
2. Insert the batteries.
3. Close the battery cover.



Please ensure the battery's polarities(+/-) match the battery compartment's polarities.

## Activating the Keyboard

1. Leave your computer on.
2. Plug the Nano Dongle directly into your computer's USB port.
3. The keyboard will automatically connect to the computer.



## Function Keys.

The keyboard has shortcut function keys which can be used as shortcuts when using the keyboard.

- Open computer folder
- Start the default e-mail program
- Start the default Web browser and load the home web page
- Turn on the Media Player program
- Mute sound
- Stop soundtrack
- Play/pause soundtrack
- Decrease the Volume
- Increase the Volume

Some function keys may not be available depending on the operating system.

## Hints and Tips

Keyboard not working:

1. Make sure the Nano Dongle is plugged into a USB port and the computer is on or try the Nano Dongle in a different USB port.
2. Check battery installation. Replace battery if needed.
3. Move the keyboard closer to the Nano Dongle.
4. Ensure your computer's operating system supports wireless input devices (e.g. mice and keyboards), and is the latest version.

## Specifications

<b>Model</b>	<b>AKBWLBL15</b>
<b>Operating Systems</b>	Microsoft® Windows® 7 / 8 / 10 MAC® OS X
<b>Battery Type</b>	2 x AAA batteries
<b>Wireless Frequency</b>	2.4GHz
<b>Operating Range</b>	10 m
<b>Frequency Band(s)</b>	2406 – 2476 MHz
<b>Max. Radio Frequency Power Transmitted</b>	Keyboard: -10 dBm Dongle: 2 dBm
<b>Dimension (L) x (W) x (H)</b>	415 x 152 x 18 mm
<b>Net Weight</b>	538 g

Features and specifications are subject to change without prior notice.

## Currys.co.uk

All the support you need. Whether it's a tech emergency or you need plain good advice, we're always on hand to help.

**UK:** 0344 5611234


**IRE:** 1 890 818 575

Visit [Partmaster.co.uk](http://Partmaster.co.uk) today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit [www.partmaster.co.uk](http://www.partmaster.co.uk) or call 0344 800 3456 (UK customers only). Calls are charged at National Rate. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. Notes for battery disposal The batteries used with this product contain chemicals that are harmful to the environment. To preserve our environment, dispose of used batteries according to your local laws or regulations. Do not dispose of batteries with normal household waste. For more information, please contact the local authority or your retailer where you purchased the product. The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

**Declaration of Conformity (RER)** Hereby, Currys Group Limited declares that the radio equipment type [AKBWLBL15] is in compliance with Radio Equipment Regulations 2017 (S.I. 2017/1206). The full text of the UK declaration of conformity is available at the following internet address:

<https://www.currys.co.uk> Click on HELP & SERVICES/Repairs & maintenance/Product Manuals and enter the model number.

## Documents / Resources

	<p><a href="#">ADVENT AKBWLBL15 Wireless Keyboard</a> [pdf] Instruction Manual AKBWLBL15, Wireless Keyboard, AKBWLBL15 Wireless Keyboard</p>
---	--

## References

- [Appliance Parts & Electrical Accessories for Home Appliances | Currys Partmaster.co.uk](#)
- [Appliance Parts & Electrical Accessories for Home Appliances | Currys Partmaster.co.uk](#)