



ADVENTRIX LED Bow and Arrow Set User Manual

Home » ADVENTRIX » ADVENTRIX LED Bow and Arrow Set User Manual

Contents

- 1 ADVENTRIX LED Bow and Arrow
- Set
- **2 INTRODUCTION**
- **3 SPECIFICATIONS**
- **4 WHAT'S IN THE BOX**
- **5 PRODUCT SIZE**
- **6 FEATURES**
- **7 SETUP GUIDE**
- 8 CARE & MAINTENANCE
- 9 TROUBLESHOOTING
- 10 PROS & CONS
- 11 WARRANTY
- 12 FREQUENTLY ASKED
- **QUESTIONS**
- 13 VIDEO PRODUCT OVERVIEW
- 14 References
- **15 Related Posts**



ADVENTRIX LED Bow and Arrow Set



INTRODUCTION

The ADVENTRIX LED Bow and Arrow Set is a fun and safe way for kids ages six and up to try shooting. This set is meant to be both fun and educational. The suction cup tip arrows are great for training accuracy without the risk of getting hurt. The bow's built-in LED lights make playing at night very fun by giving each shot launch a glow. The 27-inch bow and quiver that can hold several shots are meant to inspire creative activities outside. The set, which costs only \$24.99, has everything you need to start enjoying shooting. The LEDs on this product are powered by AA batteries, which give you hours of fun in the dark. Parents can be sure that their kids will have fun and stay safe with the ADVENTRIX LED Bow and Arrow Set, which was released by a reputable company. It can be a birthday present or something to do on the weekend.

SPECIFICATIONS

Brand Name	ADVENTRIX	
Product Name	LED Bow and Arrow Set	
Price	\$24.99	
Quiver Capacity	Holds multiple arrows	
Battery Requirement	Requires AA batteries	
LED Features	Lights up for nighttime play	
Recommended Age	Suitable for children aged 6 and up	
Arrow Type	Suction cup tip arrows	
Bow Length	27 inches	

WHAT'S IN THE BOX

- Bow and Arrow Set
- Battery
- User Manual

PRODUCT SIZE




FEATURES

- Complete Archery Kit: This set comes with a bow, 9 suction cup arrows, an arrow case, a plate target, and 3 foam targets so you can practice and have fun for hours.
- **Ergonomic Design:** The bow's ergonomic design includes a soft, kid-friendly handle that makes it easy to hold on to while playing.
- Light Effects from LEDs: The bow has two flashing LED modes, so you can play it at night or during the day.
- Value for Money: It helps kids get better at small motor skills, hand-eye coordination, and accuracy.
- Built to Last: Made from strong, high-quality materials that will hold up against rough play and handling.
- Safe Play Design: The toy has been tested and found to comply with ASTM-F963, which means it meets high safety and quality standards.
- Sticky Cup Arrows: This set has 9 arrows with sticky tips for safe and fun play indoors and outdoors.
- Small and Lightweight: It's easy to store and move because it's small and light.
- Quiver for Arrows: Comes with an arrow case that is easy to wear and has a strap for easy carrying and quick refilling.
- Fits a Range of Ages: It's best for kids aged 6 and up, but it can also be used by kids with different levels of skill
- Interactive Target Practice: It has both a plate target and a foam target to help you get better at aiming and

focusing.

• Battery-Operated Bow: The LED lights need two AA batteries, which are not included.



- Fashionable Look: It has artistic parts that make archery feel real and interesting.
- Reduces Screen Time: Promotes physical exercise through fun games that make you want to play.
- Great Gift Choice: It's fun for kids to play with and makes for a great gift for birthdays, holidays, and other special events.

SETUP GUIDE

- **Unpack the Parts:** Carefully take all of the parts out of the box, making sure that none of them are broken or missing.
- Check the Bow: Before putting the bow together or playing, check it for any loose or broken parts.
- Inserting Batteries: Open the bow's handle battery compartment and put in two AA batteries (not included).

 Then, close the compartment firmly.
- **Test LED Lights:** To make sure the LED lights work, press the button on the handle to switch between the two flashing styles.
- Assemble the Quiver: Attach the strap to the arrow case and make sure it fits your child well.

- Load Arrows into Quiver: Put the suction cup arrows in the quiver so they are easy to get to while you play.
- Set Up the Plate Target: Put the plate target far enough away and stand it up straight for target practice.
- Arrange Foam Targets: For a fun shooting experience, spread the foam targets out around the play area.
- **Teach Safe Usage:** Show your child how to safely use the bow and arrow by demonstrating proper handling and emphasizing shooting only at the designated targets.
- Nock the Arrow: Teach your child to nock an arrow by placing the suction cup end onto the bowstring.
- Pull and Release: Demonstrate the correct technique to pull the string back and release it smoothly for accurate shooting.
- Adjust Shooting Distance: Begin with shorter distances for beginners and gradually increase the range as they improve.
- Secure Play Area: Remove obstacles or breakable items from the surrounding play area to prevent accidents.
- Supervise Play: Always keep an eye on children while they use the set, especially when playing with others.
- Turn Off LEDs: Save battery life by pressing the button to turn off the LED lights when not in use.

CARE & MAINTENANCE

- Clean After Use: Wipe the bow, arrows, and targets with a soft, damp cloth after each use to keep them clean.
- Check Regularly: Inspect the bowstring and suction cup arrows for damage and replace parts as needed.
- Store Safely: Keep the set in a cool, dry place to protect it from moisture or extreme temperatures.
- Remove Batteries: Take out batteries when the set is not in use for an extended period to prevent leakage.
- Avoid Overstretching: Teach kids not to stretch the bowstring excessively to maintain its flexibility.
- Protect LEDs: Prevent damage to the LED system by avoiding drops or water exposure.
- Clean Targets: Regularly clean the plate and foam targets to ensure optimal suction for arrows.
- Secure Arrows: Keep arrows properly stored in the quiver to prevent loss or damage.
- Check for Loose Parts: Periodically tighten any screws or fittings on the bow or quiver.
- Do Not Overload Quiver: Avoid overloading the quiver to prevent wear on the strap or case.
- Replace Batteries Promptly: Replace drained batteries immediately to ensure uninterrupted performance.
- Supervise Younger Kids: Keep an eye on younger children to ensure they use the set safely and correctly.
- Avoid Excessive Force: Encourage gentle handling to preserve the bow and arrow set's durability.
- Use Gentle Cleaners: Avoid harsh chemicals that may damage the materials or finishes.
- Align LED Batteries: If LED lights fail to work, double-check the battery alignment or replace them with fresh ones.

TROUBLESHOOTING

Issue	Possible Cause	Solution
LED lights not working	Batteries depleted	Replace with fresh AA batteries.
Arrows not sticking to targets	Dust on suction cups	Clean the suction cups with a damp cloth.
Bowstring not pulling smoothly	Tangled or misaligned strin	Check and realign the string properly.
LED lights flickering	Loose battery connection	Ensure batteries are properly inserted.
Arrows not firing far	Weak tension in bowstring	Check for wear and tighten the string gently.
Difficulty loading arrows	Quiver misaligned	Adjust quiver to a more accessible position.
Quiver not holding arrows securel y	Overloaded quiver	Reduce the number of arrows in the quiver.
LED lights dimming	Low battery charge	Replace batteries with new ones.
Arrows breaking on impact	Hard surface target	Use softer or recommended target surfaces.
Bowstring detaching	Improper assembly	Reattach string securely according to manual .
Arrows slipping during load	Misaligned grip	Align arrows correctly in the bow slot.
Quiver strap too tight/loose	Incorrect adjustment	Adjust strap to fit the user comfortably.
LED light cover loose	Loose screws or fittings	Tighten screws gently without over-tightening .
Bow losing tension	Prolonged use	Replace or tighten bowstring as needed.
Suction cups deforming	Overuse or heat exposure	Soak suction cups in warm water to reshape.

PROS & CONS

Pros:

- 1. LED lights enhance nighttime play.
- 2. Safe suction cup arrows for worry-free fun.
- 3. Lightweight and easy for kids to handle.
- 4. The affordable price point for families.
- 5. Encourages outdoor and active play.

Cons:

- 1. Requires AA batteries, not included.
- 2. LED light lifespan may vary with usage.
- 3. Arrows may lose suction grip over time.
- 4. Limited to younger age groups (6+).
- 5. The quiver can only hold a few arrows at once.

WARRANTY

ADVENTRIX offers a **30-day limited warranty** for the LED Bow and Arrow Set. The warranty covers manufacturing defects and faulty components but does not include damage caused by misuse, wear and tear, or improper maintenance.

FREQUENTLY ASKED QUESTIONS

What is the price of the ADVENTRIX LED Bow and Arrow Set?

The ADVENTRIX LED Bow and Arrow Set is priced at \$24.99, making it an affordable and fun activity for children.

What type of arrows does the ADVENTRIX LED Bow and Arrow Set include?

The ADVENTRIX LED Bow and Arrow Set includes suction cup tip arrows, designed for safe and interactive play.

How long is the bow in the ADVENTRIX LED Bow and Arrow Set?

The bow in the ADVENTRIX LED Bow and Arrow Set measures 27 inches, providing a comfortable size for young archers.

Does the ADVENTRIX LED Bow and Arrow Set feature LED lights?

ADVENTRIX LED Bow and Arrow Set is equipped with LED lights, enhancing the fun for nighttime play.

What is the recommended age range for the ADVENTRIX LED Bow and Arrow Set?

The ADVENTRIX LED Bow and Arrow Set is recommended for children aged 6 years and up, ensuring it is suitable for this age group.

What type of batteries does the ADVENTRIX LED Bow and Arrow Set require?

The ADVENTRIX LED Bow and Arrow Set requires AA batteries to power its LED lighting feature.

How many arrows can the quiver in the ADVENTRIX LED Bow and Arrow Set hold?

The quiver included in the ADVENTRIX LED Bow and Arrow Set can hold multiple arrows, offering convenient storage during play.

Can the ADVENTRIX LED Bow and Arrow Set be used in low-light conditions?

Absolutely! The ADVENTRIX LED Bow and Arrow Set features LED lights, making it ideal for nighttime or low-light play sessions.

What makes the LED lights on the ADVENTRIX LED Bow and Arrow Set unique?

The LED lights on the ADVENTRIX LED Bow and Arrow Set enhance the gameplay by illuminating the bow, creating an exciting effect during play.

How does the ADVENTRIX LED Bow and Arrow Set encourage creativity?

The ADVENTRIX LED Bow and Arrow Set promotes imaginative play by allowing children to pretend they are skilled archers in exciting scenarios.

What makes the ADVENTRIX LED Bow and Arrow Set suitable for children?

The ADVENTRIX LED Bow and Arrow Set is safe, lightweight, and features a 27-inch bow with suction cup arrows, perfect for young users.

How does the ADVENTRIX LED Bow and Arrow Set enhance nighttime play?

The LED lights in the ADVENTRIX LED Bow and Arrow Set provide visibility in the dark, adding an extra layer of fun to nighttime activities.

How durable is the ADVENTRIX LED Bow and Arrow Set?

The ADVENTRIX LED Bow and Arrow Set is built from sturdy materials and designed to withstand regular use by children, ensuring lasting fun.

Why isn't the LED on the ADVENTRIX LED Bow and Arrow Set turning on?

Check the battery compartment to ensure the batteries are inserted correctly. Replace old or dead batteries with new ones to restore functionality.

The suction cups on the arrows of my ADVENTRIX LED Bow and Arrow Set don't stick to the target. What should I do?

Clean the suction cups with warm water and mild soap to remove dust or debris. Dry them thoroughly before use. Ensure the target surface is smooth and clean.

<u>VIDEO – PRODUCT OVERVIEW</u>



Referencesals.plus/wp-content/uploads/2024/11/ADVENTRIX-LED-Bow-and-Arrow-Set-User-Manual.mp4

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.