

AEi VM-8208-SMK Analog DECT Phone User Manual

Contents

- [1 AEi VM-8208-SMK Analog DECT Phone](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Documents / Resources](#)

AEi VM-8208-SMK Analog DECT Phone

Product Information

The Analog DECT Phone (VM-8208-SMK(A) / VM-8108-SMK(A)) is a full-feature telephone that provides voice communication. It is equipped with various features to enhance your communication experience.

Package Contents

- Base Unit
- Handset
- Stand
- AC Adaptor
- RJ-45 Cable
- Quick Installation Guide (QIG)

Product Description

The Analog DECT Phone has a base unit and a handset. Here are the key features and functions:

Base Unit Front View

- Programmable Services keys: Press to call preset services.
- Alphanumerical keys: Enter phone numbers and texts.
- Function keys:
 - LINE 1 / LINE 2: Indicate the status of the lines (Idle, Call on hold, In call) and put an active call on hold.
 - MUTE (single line only): Mute the microphone.
 - REDIAL: Call the last dialed number.
 - SPEAKER: Activate the speakerphone for hands-free conversations.
 - VOLUME UP/DOWN: Increase or decrease the volume of the ringer tone or speakerphone.
 - MESSAGE: Retrieve voice messages.

Handset Keys

- Display screen: Shows calls and status information.
- SELECT: Enter service function.
- SERVICES key: Choose service function.
- Right / Left key: Navigate through options.
- LINE 1 / LINE 2: Two lines for phone calls.
- END key: End the phone call.
- Alphanumerical keys: Enter phone numbers and texts.
- Function keys:
 - HOLD (2 line only): Put an active call on hold.
 - MUTE (single line only): Mute the microphone.
 - SPEAKER: Activate the speakerphone for hands-free conversations.
 - VOLUME: Adjust the volume of the ringer tone, handset, or speakerphone.
 - MESSAGE: Listen to voice messages.
 - GUEST SERVICES: Contact guest services.
 - EMERGENCY: Make an emergency call.

Base Unit Back View

- DC Power jack: Connects to AC power adapter.
- PSTN line port: Connects to PSTN line.

Product Usage Instructions

Connecting the Phone

To connect the phone:

1. Connect the DC Power jack to the AC power adapter.
2. Connect the PSTN line port to the PSTN line.

Operation

Answering a Call

To answer a call:

- Pick up the Handset to answer the call.
- Press the LINE (LINE1/LINE2) key on the base or handset to answer the call.

Making a Call


To make a call:

- Dialing with the Keypad: Enter the telephone number using the alphanumerical keypad.
- After entering the number you want to call, press the # key to force dialing or wait for 4 seconds before the number is dialed automatically.

Using the Programmable Services keys

The Programmable Services keys can be used to call preset services. Press the corresponding key to initiate the desired service.

Documents / Resources

<div><div><div>Analogue DECT Phone</div><div></div><div>VM-8208-SMK/CT, VM-8208-SMK/CT QRC V 1.01</div></div></div>	<div><div>AEi VM-8208-SMK Analogue DECT Phone [pdf] User Manual</div><div>VM-8208-SMK, VM-8108-SM, VM-8208-SMK Analogue DECT Phone, VM-8208-SMK, Analogue DECT Phone, DECT Phone, Phone</div></div>
--	---