



AeroCool Quantum/Quantum Mesh Mditower User Manual

[Home](#) » [AeroCool](#) » AeroCool Quantum/Quantum Mesh Mditower User Manual 

AeroCool Quantum/Quantum Mesh Mditower User Manual




Contents

- [1 Front I/O Cable Connection](#)
- [2 Accessory Bag Contents](#)
- [3 How to Install](#)
- [4 I/O Panel](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)


Front I/O Cable Connection

Front I/O Connectors

(Please refer to the motherboard's manual for further instructions).



Note Specifications may vary depending on your region. Contact your local retailer for more information.



Accessory Bag Contents

1. SSD Screw MB Screw



2. PSU Screw PCI Screw



3. HDD Screw



4. 3.5* HDD Sliding Screw for (4b)




5. MB Standoff




6. Cable tie

How to Install


1. Install Motherboard




2. Install PSU




3. Install Add-on-Card




4. a. Install 3.5" HDD x1




b. Install 3.5" HDD x1





5. a. Install 2.5" SSD x2









b. Install 2.5" SSD x 2 (only for Mini-ITX M/B)




6. a. Install Front Radiator




7. a. Install Front Fans




b. Install Rear Fan




c. Install Top Fans



d. Install PSU Fans




I/O Panel



Press and hold LED Control Button for 3 sec to turn off LED. (For RGB Version Only)

Note: Specifications may vary depending on your region. Contact your local retailer for more information.

Documents / Resources



[AeroCool Quantum/Quantum Mesh Midtower \[pdf\] User Manual](#)
Quantum, Quantum Mesh, Midtower

References

-  [ANDPRO.RU](https://andpro.ru) - интернет магазин компьютерной и офисной техники с выгодными ценами и доставкой