



AeroCool Stark Mini Micro-ATX Case User Manual

[Home](#) » [AeroCool](#) » AeroCool Stark Mini Micro-ATX Case User Manual 

AeroCool Stark Mini Micro-ATX Case User Manual




Contents

- [1 Front I/O Panel Cable Connection](#)
- [2 Accessory Bag Contents](#)
- [3 How to install Guide](#)
- [4 I/O Panel](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)


Front I/O Panel Cable Connection

Front Panel Connector

(Please refer to the motherboard's manual for further instructions).



Note: Specifications may vary depending on your region. Contact your local retailer for more information.



Accessory Bag Contents

1. SSD Screw MB Screw ODD Screw



2. HDD Screw



3. PSU Screw PCI Screw




4. MB Standoff




How to install Guide


Install Motherboard





Install PSU





Install add-on-card




Install 3.5" Drive




Install 5.25" ODD




Install SSD x1




Install SSD x1




Install SSD x1




Install HDD x2



Install Front Fan




I/O Panel



Note: Specifications may vary depending on your region. Contact your local retailer for more information.

Documents / Resources



[AeroCool Stark Mini Micro-ATX Case](#) [pdf] User Manual
Stark Mini, Micro-ATX Case, Stark Mini Micro-ATX Case, Case