



AeroCool VX Plus 400W Power Unit User Manual

[Home](#) » [AeroCool](#) » AeroCool VX Plus 400W Power Unit User Manual 



VX Plus 400W Power Unit
User Manual



POWER SUPPLY USER MANUAL

Contents

1 Safety Reminders

2 Documents / Resources

2.1 References

3 Related Posts

Safety Reminders

Before installation :

- Make sure that the wattage and output of your PSU are enough to power your system's requirements.
- Make sure that the power cord is disconnected and that the PSU switch is turned off.
- This PSU was designed for NON-INDUSTRIAL desktop systems according to INTEL's Desktop Platform Form Factors. Usage outside of these parameters, including cryptocurrency mining, might cause overheating, malfunction, or damage to your equipment and will void your warranty.
- DO NOT attempt to expand the connectors through adapters or other means.
- DO NOT operate in wet or damp conditions.
- Do NOT open the PSU casing, the unit operates with hazardous voltages, and there is no serviceable component inside.
- Do NOT remove the warranty sticker. Damage or removal of the sticker will void your warranty.
- Please visit Aero cool official website www.aerocool.com.tw for details on your PSU warranty policy.



Documents / Resources

	AeroCool VX Plus 400W Power Unit [pdf] User Manual VX Plus 400W Power Unit, VX Plus, 400W Power Unit, Power Unit, Unit
---	---

References

-  [AeroCool - AeroCool](#)