

Aeropulse Fusion Apollo Marine Amplifier Unbox Installation Guide


Home » Aeropulse » Aeropulse Fusion Apollo Marine Amplifier Unbox Installation Guide 🖺






Step 1


Insert the sensor or battery capsule at a 30-degree angle into the designated slot. Once aligned, press down on the top side of the capsule to secure it in place.




Step 2Position the cover over the capsules and press down firmly on the upper part to ensure a secure ft.



Step 3Attach the small bracket onto the device and secure it using three screws.



Step 4Mount the larger bracket onto the wall and secure it with screws



Step 5
Connect the necessary power and connectivity cables:

Power Cable


- Connect 10-30V DC or 24V AC to the +/- terminals on the connectivity port.
- For Poe, connect to the Ethernet port

Connectivity Cables

- $\circ\,$ Connect Modbus or BACnet cables to the A/B terminals on the connectivity port.
- Connect the Ethernet cable to the Ethernet port.

Step 6


Slide the device vertically into the wall-mounted brackets until securely positioned.



Contents

- 1 Documents / Resources
 - 1.1 References
- **2 Related Posts**

Documents / Resources



<u>Aeropulse Fusion Apollo Marine Amplifier Unbox</u> [pdf] Installation Guide Fusion Apollo Marine Amplifier Unbox, Apollo Marine Amplifier Unbox, Marine Amplifier Unbox, Amplifier Unbox

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.