



Aerpro SWSU8C Steering Wheel Control Interface



Aerpro SWSU8C Steering Wheel Control Interface Installation Guide


[Home](#) » [Aerpro](#) » Aerpro SWSU8C Steering Wheel Control Interface Installation Guide 

Contents

- [1 Aerpro SWSU8C Steering Wheel Control Interface](#)
- [2 Product Usage Instructions](#)
- [3 KEY FEATURES](#)
- [4 PRIOR TO INSTALLATION](#)
- [5 DIPSWITCH CONFIGURATION](#)
- [6 CONNECTION GUIDE](#)
- [7 INSTALLATION](#)
- [8 STEERING WHEEL CONTROL CONFIGURATION](#)
- [9 CONNECTION DIAGRAM](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



Aerpro SWSU8C Steering Wheel Control Interface



Product Specifications

- Product Name: Steering Wheel Control Interface for Subaru Vehicles
- Model Number: SWSU8C
- Compatibility: Subaru Outback, Forester (SJ), Impreza (GP, GJ), XV, WRX (MY15) – Year Range: 2009-2015

Product Usage Instructions

Installation Guide

The SWSU8C allows for the retention of steering wheel controls and other features when installing an aftermarket unit in your Subaru vehicle. Follow the provided table for the correct dipswitch configuration.

Vehicle Application:

To suit Subaru vehicles including Outback, Forester, Impreza, XV, and WRX within the specified year range.

Key Features

- Retains steering wheel controls
- Selectable dipswitches for dedicated applications
- Ensures seamless integration

Prior to Installation

Installation requires technical knowledge. Read the manual before starting. Choose a dry, heat-free installation location. Use correct tools to prevent damage. Disconnect the negative battery terminal and remove the ignition key before installation.

Frequently Asked Questions (FAQ)

Q: What should I do if the steering wheel controls are not working after installation?

A: Check the dipswitch configuration according to the provided table. Make sure all connections are secure and

properly installed.

Q: Can this interface be used with other vehicle brands?

A: This interface is specifically designed for Subaru vehicles and may not be compatible with other brands.

INSTALLATION GUIDE

The SWSU8C allows for the retention of the steering wheel controls as well as other vital features when installing an aftermarket unit into the vehicle. This interface features selectable dipswitches for dedicated applications, simply refer to the provided table for the correct configuration ensuring seamless integration.

VEHICLE APPLICATION

To Suit SUBARU

- Outback 2009-2014
- Forester (SJ) 2013-2014
- Impreza (GP, GJ) 2012-2014
- XV 2012-2015
- WRX (MY15) 2014-2015
- VISIT AERPRO.COM FOR FACTORY
- HEAD UNIT COMPATIBILITY


KEY FEATURES

- RETAIN STEERING WHEEL CONTROL FUNCTIONALITY
- REPLACE FACTORY RADIO
- OUTPUTS FOR REVERSE GEAR
- SOFTWARE UPDATEABLE
- REMAPPABLE BUTTONS


PRIOR TO INSTALLATION

Installation requires a certain level of technical knowledge. Prior to installation, it is important to read the manual. Select a location for installation that is dry and free from heat sources. It is essential to use the correct tools during installation to prevent any damage to the vehicle or the product itself. Please note that we cannot be held liable for any issues arising from improper installation.


Before proceeding with installation, disconnect the negative battery terminal and ensure the key is removed from the ignition.




**18 PIN HARNESS
CONNECTOR**



DIPSWITCHES



**16-PIN HEAD UNIT
CONNECTION LEAD**



USB-C

WIRING KEY

ISO CONNECTOR WIRING KEY

- Purple Right Rear Speaker +
- Purple/Black Right Rear Speaker –
- Green Left Rear Speaker +
- Green/Black Left Rear Speaker –
- Grey Right Front Speaker +
- Grey/Black Right Front Speaker –
- White Left Front Speaker +
- White/Black Left Front Speaker –
- Yellow Permanent 12V
- Black Ground
- Red Ignition 12V
- Orange Illumination

FLYING WIRE WIRING KEY

- Purple/White Reverse Gear – 250mA

OUTPUTS & RATINGS

- Standby Current <3mA
- Operating Voltage 6V to 16V
- Operating Temperature -20C to 85C

*rated at 25 degrees Centigrade

DIPSWITCH CONFIGURATION

| MANUFACTURER | SYSTEM | DIPSWITCH CONFIGURATION | | | | CONNECTION |
|----------------------|---------|-------------------------|-----|-----|-----|----------------------|
| | | 1 | 2 | 3 | 4 | |
| RESERVED | NA | OFF | OFF | OFF | OFF | SOFTWARE UPDATE MODE |
| AERPRO | Analog | OFF | OFF | ON | ON | MALE 3.5MM JACK |
| ALPINE | IR DATA | OFF | ON | OFF | OFF | MALE 3.5MM JACK |
| ANALOG SINGLE EXTEND | Analog | ON | ON | ON | ON | BROWN SWC IR |
| ANALOG SINGLE WIRE | Analog | ON | ON | ON | OFF | BROWN SWC IR |
| CLARION | IR DATA | ON | OFF | OFF | ON | MALE 3.5MM JACK |
| CUSTOM | IR DATA | ON | OFF | ON | OFF | HEAD UNIT DEPENDANT |
| GRUNDIG | IR DATA | OFF | ON | OFF | ON | BROWN SWC IR |
| JVC | IR DATA | OFF | OFF | ON | OFF | BROWN SWC IR |
| KENWOOD 1 | IR DATA | ON | OFF | OFF | OFF | BROWN SWC IR |
| KENWOOD 2 | IR DATA | ON | ON | OFF | OFF | BROWN SWC IR |
| KEY 1 / KEY 2 | Analog | OFF | ON | ON | OFF | KEY1 / KEY 2 WIRES |
| KEY 1 / KEY 2 EXTEND | Analog | OFF | ON | ON | ON | KEY1 / KEY 2 WIRES |
| PHILIPS | IR DATA | OFF | ON | OFF | ON | BROWN SWC IR |
| PIONEER 1 | Analog | OFF | OFF | OFF | ON | MALE 3.5MM JACK |
| PIONEER 2 | Analog | OFF | OFF | ON | ON | MALE 3.5MM JACK |
| SONY | Analog | ON | OFF | ON | ON | MALE 3.5MM JACK |


DIPSWITCH 5 & 6

Dipswitch 5 is reserved for vehicle specific configuration.


Dipswitch 6 can be switched if the steering wheel controls in your vehicle are sending the wrong information. For the SWSU8C it should be set to Dipswitch 6 ON as default. Switch to OFF if your steering wheel control buttons are mixed up.

| | |
|---|--|
| KEY1 and KEY 2 | KEY1 and KEY2 are specifically tailored for analog learning mode-style radios. Our SWC module is designed with a resistor chain that precisely matches the required resistance for seamless compatibility with this type of head unit. |
| KEY1 and KEY 2 EXTEND | This mode extends every button press to 2 seconds during the learning process. However, with rotary wheel-designed steering wheel buttons, holding for 2 seconds isn't feasible. Our KEY1 and KEY2 extend feature addresses this by automatically prolonging each press, simplifying head unit programming even in such scenarios. Extend mode is not intended for normal use, it is only used in the teaching process. |
| ANALOG SINGLE WIRE and ANALOG SINGLE WIRE EXTEND | <p>This function operates similarly to KEY1 and KEY2 but transmits all unique values through the IR SWC single wire. This is crucial for compatibility with learning-style head units featuring only one learning input wire. To ensure compatibility, we've incorporated this feature into our steering wheel control interface, ensuring seamless operation across various head unit setups.</p> <p>The Analog Extend mode functions identically to its counterpart within the KEY1 and KEY2 system but transmits through a single wire.</p> |


SWC INTERFACE




18 PIN HARNESS CONNECTOR



DIPSWITCHES



16-PIN HEAD UNIT CONNECTION LEAD



USB-C


CONNECTION GUIDE

BEFORE INSTALLATION

Prior to installing the interface, it is essential to remove and disconnect the factory stereo. For guidance on this process, please refer to the vehicle owner's manual/handbook or seek assistance from a professional.

SETTING THE DIPSWITCHES

This interface includes a set of dipswitches. Consult the dipswitch selection guide to select the appropriate configuration. To activate a dipswitch, press it downward into the 'ON' position. Refer to the diagram for an example of the 'KENWOOD1' dipswitch configuration.



INSTALLATION

1. Take the interface, then connect the 16-PIN head unit connection lead and the 18-PIN steering wheel harness connectors to their respective ports.

2. Connect the head unit connection lead to the steering wheel remote input on the rear side of the aftermarket stereo.

Connection methods vary based on the stereo brand, utilising either a 3.5mm jack connector SWC IR wire or wired inputs KEY1 and KEY2.

For specific connection guidance, refer to your aftermarket stereo's installation manual if not clearly labelled on the stereo harness.

3. Connect the power/speaker ISO connector from the interface to the corresponding power/speaker ISO connection on the aftermarket stereo.

For aftermarket stereos lacking an ISO connector, refer to the "Wiring Key" on Page 2 for guidance on connecting wires. Certain interfaces may also include extra "flying" wires for additional functionalities such as parking brake trigger, reverse gear, and speed pulse. Further information on these wires is available in the "Flying Wire Wiring Key" section.

4. Connect the vehicle-specific connectors from the interface harness to the corresponding connectors on the vehicle harness.
5. Connect the flying wires on the harness to the rear of the stereo (iff applicable).
6. Connect the antenna adapter to the vehicle's existing connection at the rear of the aftermarket stereo.
7. When installing an aftermarket reverse camera, connect the yellow RCA from the harness to the yellow RCA of the aftermarket camera. (If supported by the interface and vehicle)
8. When installing a DAB antenna, ensure to connect the DAB aerial connector to the rear of the new stereo.
9. After connecting all wires (along with any additional accessories), it's crucial to thoroughly test the stereo and steering wheel controls before reassembling the dashboard. If steering wheel controls are unresponsive, inspect connections and check dipswitch settings. Repeat the connection process if necessary, following the outlined steps.

STEERING WHEEL CONTROL CONFIGURATION



- A Volume Up
- B Volume Down
- C Track Up
- D Track Down
- E Source
- F Mute
- G Pick Up
- H Hang Up
- I Voice Control

BUTTON REMAPPING

The steering wheel buttons listed offer the flexibility of being re-configured or assigned dual functions. The availability of these buttons depends on the specific vehicle to which the interface is being installed and if the aftermarket radio supports them.


In addition to button remapping, we offer the option to assign dual functions to each button on the steering wheel. This means that every button can be programmed to execute both a short press command and a long press command.

You can also add your own bespoke configuration. Button configuration can be done by PC, MAC and smart phone via the USB port.


Button Remapping instructions can be found in a separate guide on our website.

CONNECTION DIAGRAM


HEAD UNIT CONNECTION LEAD



SWC INTERFACE



SWC VEHICLE HARNESS





[Aerpro SWSU8C Steering Wheel Control Interface](#) [pdf] Installation Guide
SWSU8C Steering Wheel Control Interface, SWSU8C, Steering Wheel Control Interface, Wheel Control Interface, Control Interface, Interface

References

- [Home](#) | [Aerpro](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.